




18 CALDIA LT 1000S-P

Feel Alive.



REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
18 CALDIA LT 1000S-P	S39110E	1	6J697001	DRAG KNOB
18 CALDIA LT 1000S-P	S39110E	2	6J547101	DRAG RING
18 CALDIA LT 1000S-P	S39110E	3	6J547001	DRAG DISC WASHER
18 CALDIA LT 1000S-P	S39110E	4	6J678801	ATD DRAG WASHER (1 pack - 3pcs)
18 CALDIA LT 1000S-P	S39110E	5	-	DRAG LIP WASHER
18 CALDIA LT 1000S-P	S39110E	6	-	DRAG DISC WASHER
18 CALDIA LT 1000S-P	S39110E	7	6J563601	LINE STOPPER PLATE
18 CALDIA LT 1000S-P	S39110E	8	6J558001	LINE STOPPER
18 CALDIA LT 1000S-P	S39110E	9	6J314801	LINE STOPPER SPRING
18 CALDIA LT 1000S-P	S39110E	10	6J696701	SPOOL ASSY (2 ~ 10)
18 CALDIA LT 1000S-P	S39110E	11	6E398000	SPOOL WASHER (A)
18 CALDIA LT 1000S-P	S39110E	12	6E467101	SPOOL WASHER (B)
18 CALDIA LT 1000S-P	S39110E	13	6J525101	CLICK LEAF SPRING
18 CALDIA LT 1000S-P	S39110E	14	6J546201	CLICK HOLDER
18 CALDIA LT 1000S-P	S39110E	15	6J703101	CLICK HOLDER WASHER
18 CALDIA LT 1000S-P	S39110E	16	6H986901	ROTOR NUT PACKING
18 CALDIA LT 1000S-P	S39110E	17	6H961101	ROTOR NUT
18 CALDIA LT 1000S-P	S39110E	18	6H022701	ROTOR NUT SCREW
18 CALDIA LT 1000S-P	S39110E	19	6H974326	ROTOR
18 CALDIA LT 1000S-P	S39110E	20	6H443301	KICK LEVER SPRING
18 CALDIA LT 1000S-P	S39110E	21	6H443401	KICK LEVER ASSY
18 CALDIA LT 1000S-P	S39110E	22	6H417701	KICK LEVER SCREW
18 CALDIA LT 1000S-P	S39110E	23	6H443601	ARM LEVER SHAFT
18 CALDIA LT 1000S-P	S39110E	24	6H576101	ARM LEVER SHAFT PLATE
18 CALDIA LT 1000S-P	S39110E	25	6H442401	ARM LEVER SHAFT SPRING
18 CALDIA LT 1000S-P	S39110E	26	6H414301	ARM LEVER SHAFT HOLDER
18 CALDIA LT 1000S-P	S39110E	27	6H974401	ARM LEVER SP COVER
18 CALDIA LT 1000S-P	S39110E	28	6H431301	ARM LEVER SP COVER SCREW
18 CALDIA LT 1000S-P	S39110E	29	6H960102	ARM LEVER
18 CALDIA LT 1000S-P	S39110E	30	6H962401	ARM LEVER COLLAR
18 CALDIA LT 1000S-P	S39110E	31	6H431201	ARM LEVER SCREW
18 CALDIA LT 1000S-P	S39110E	32	6H697701	ROLLER SCREW
18 CALDIA LT 1000S-P	S39110E	33	6H961001	ROLLER COLLAR (A)
18 CALDIA LT 1000S-P	S39110E	34	6H038301	ROLLER BEARING PACKING
18 CALDIA LT 1000S-P	S39110E	35	6G686903	ROLLER BALL BEARING
18 CALDIA LT 1000S-P	S39110E	36	6H960901	ROLLER BEARING COLLAR
18 CALDIA LT 1000S-P	S39110E	37	6G686703	LINE ROLLER
18 CALDIA LT 1000S-P	S39110E	38	6H960801	ROLLER COLLAR (B)
18 CALDIA LT 1000S-P	S39110E	39	6H960701	ROLLER COLLAR (C)
18 CALDIA LT 1000S-P	S39110E	40	6H974501	BAIL ASSY
18 CALDIA LT 1000S-P	S39110E	41	6H431201	BAIL HOLDER SCREW
18 CALDIA LT 1000S-P	S39110E	42	6J429301	MAGSEALED PLATE SCREW
18 CALDIA LT 1000S-P	S39110E	43	6J675201	MAGSEALED PLATE
18 CALDIA LT 1000S-P	S39110E	44	6J354801	MAGSEALED PLATE ORING
18 CALDIA LT 1000S-P	S39110E	45	6J445901	MAGSEALED CAP
18 CALDIA LT 1000S-P	S39110E	46	6J639900	ONEWAY CLUTCH WASHER
18 CALDIA LT 1000S-P	S39110E	47	6J388401	ONEWAY CLUTCH
18 CALDIA LT 1000S-P	S39110E	48	6G997301	PINION BEARING PLATE SCREW
18 CALDIA LT 1000S-P	S39110E	49	6J001403	CLUTCH RING
18 CALDIA LT 1000S-P	S39110E	50	6H442201	PINION BEARING PLATE
18 CALDIA LT 1000S-P	S39110E	51	6G467302	PINION BALL BEARING (A)
18 CALDIA LT 1000S-P	S39110E	52	63758500	PINION BEARING WASHER
18 CALDIA LT 1000S-P	S39110E	53	6Z023903	PINION + DRIVE GEAR SET
18 CALDIA LT 1000S-P	S39110E	54	6J683001	PINION BEARING SPRING WASHER
18 CALDIA LT 1000S-P	S39110E	55	6H959601	PINION BALL BEARING (B)
18 CALDIA LT 1000S-P	S39110E	56	-	PINION COLLAR WASHER
18 CALDIA LT 1000S-P	S39110E	57	6J387701	PINION COLLAR
18 CALDIA LT 1000S-P	S39110E	58	6J696901	BODY ASSY
18 CALDIA LT 1000S-P	S39110E	59	6J559702	MAIN SHAFT
18 CALDIA LT 1000S-P	S39110E	60	6J526101	OSCILLATING POST
18 CALDIA LT 1000S-P	S39110E	61	6H595501	STOPPER CAM
18 CALDIA LT 1000S-P	S39110E	62	6H595401	STOPPER LEVER
18 CALDIA LT 1000S-P	S39110E	63	6H697801	STOPPER CAM LEAF SPRING
18 CALDIA LT 1000S-P	S39110E	64	6J524901	REAR CAP
18 CALDIA LT 1000S-P	S39110E	65	6J389001	REAR CAP SCREW
18 CALDIA LT 1000S-P	S39110E	66	6H607902	OSCILLATING GEAR WASHER
18 CALDIA LT 1000S-P	S39110E	67	6J535801	OSCILLATING GEAR
18 CALDIA LT 1000S-P	S39110E	68	6G683301	OSCILLATING GEAR ORING
18 CALDIA LT 1000S-P	S39110E	69	6H129200	OSCILLATING GEAR BALL BEARING WASHER
18 CALDIA LT 1000S-P	S39110E	70	6G469005	OSCILLATING GEAR BALL BEARING
18 CALDIA LT 1000S-P	S39110E	71	6G997001	OSCILLATING GEAR BALL BEARING SCREW
18 CALDIA LT 1000S-P	S39110E	72	6G670501	DRIVE GEAR ORING
18 CALDIA LT 1000S-P	S39110E	73	63758500	DRIVE WASHER
18 CALDIA LT 1000S-P	S39110E	74	6G467302	DRIVE GEAR BALL BEARING (A)
18 CALDIA LT 1000S-P	S39110E	75	6J628803	BODY COVER ASSY
18 CALDIA LT 1000S-P	S39110E	76	6J389801	BODY COVER SCREW
18 CALDIA LT 1000S-P	S39110E	77	6J130201	HANDLE CAP PACKING
18 CALDIA LT 1000S-P	S39110E	78	6J696601	HANDLE ASSY
18 CALDIA LT 1000S-P	S39110E	79	6G522706	DRIVE GEAR BALL BEARING (B)
18 CALDIA LT 1000S-P	S39110E	80	6G472401	DRIVE BEARING RING
18 CALDIA LT 1000S-P	S39110E	81	6G162401	HANDLE CAP ORING
18 CALDIA LT 1000S-P	S39110E	82	6J389701	HANDLE CAP