




AGGREST LT 2500

Feel Alive.



REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
AGGREST LT 2500	S41405N	1	6Q346201	DRAG KNOB
AGGREST LT 2500	S41405N	2	6Q346101	DRAG RING
AGGREST LT 2500	S41405N	3	6J547001	DRAG DISC WASHER
AGGREST LT 2500	S41405N	4	6J546801	DRAG WASHER
AGGREST LT 2500	S41405N	5	6Q346001	DRAG LIP WASHER
AGGREST LT 2500	S41405N	2~6	6Q485501	SPOOL ASSY (2-6)
AGGREST LT 2500	S41405N	7	6Q348502	SPOOL WASHER (A)
AGGREST LT 2500	S41405N	8	6E398003	SPOOL WASHER (B)
AGGREST LT 2500	S41405N	9	6Q457701	CLICK LEAF SPRING
AGGREST LT 2500	S41405N	10	6Q457601	CLICK HOLDER
AGGREST LT 2500	S41405N	11	6Q344001	ROTOR WASHER
AGGREST LT 2500	S41405N	12	6Q122401	ROTOR NUT
AGGREST LT 2500	S41405N	13	6H022701	ROTOR NUT SCREW
AGGREST LT 2500	S41405N	14	6Q343008	ROTOR
AGGREST LT 2500	S41405N	15	6H413601	KICK LEVER SPRING
AGGREST LT 2500	S41405N	16	6Q343101	KICK LEVER
AGGREST LT 2500	S41405N	17	6H417701	KICK LEVER SCREW
AGGREST LT 2500	S41405N	18	6Q343301	ARMLEVER SHAFT
AGGREST LT 2500	S41405N	19	6H576101	ARMLEVER SHAFT PLATE
AGGREST LT 2500	S41405N	20	6J642801	ARMREVER SPRING
AGGREST LT 2500	S41405N	21	6Q121501	ARMLEVER SPRING HOLDER
AGGREST LT 2500	S41405N	22	6Q343501	ARMLEVER SPRING COVER
AGGREST LT 2500	S41405N	23	6G205001	ARMLEVER SPRING COVER SCREW
AGGREST LT 2500	S41405N	24	6Q121606	ARM LEVER
AGGREST LT 2500	S41405N	25	6Q121701	ARMLEVER SCREW COLLER
AGGREST LT 2500	S41405N	26	6G205001	ARMLEVER SCREW
AGGREST LT 2500	S41405N	27	6G195602	ROLLER SCREW
AGGREST LT 2500	S41405N	28	6G195501	ROLLER COLLAR (A)
AGGREST LT 2500	S41405N	29	6G220701	ROLLER COLLAR (B)
AGGREST LT 2500	S41405N	30	6J089903	LINE ROLLER
AGGREST LT 2500	S41405N	31	6Q203401	ROLLER COLLAR (C)
AGGREST LT 2500	S41405N	32	6Q457501	BAIL
AGGREST LT 2500	S41405N	33	-----	-----
AGGREST LT 2500	S41405N	34	6G837101	ONEWAY CLUTCH PLATE SCREW
AGGREST LT 2500	S41405N	35	6Q139401	ONEWAY CLUTCH PLATE
AGGREST LT 2500	S41405N	36	6Q308301	ONEWAY CLUTCH
AGGREST LT 2500	S41405N	37	6J001401	CLUTCH RING
AGGREST LT 2500	S41405N	38	6Q126201	PINION BEARING PLATE SCREW
AGGREST LT 2500	S41405N	39	6H442201	PINION BEARING PLATE
AGGREST LT 2500	S41405N	40	6G467302	PINION BALL BEARING
AGGREST LT 2500	S41405N	41	6Q457201	PINION GEAR
AGGREST LT 2500	S41405N	42	-----	-----
AGGREST LT 2500	S41405N	43	6Q485301	BODY
AGGREST LT 2500	S41405N	44	6Q341501	MAIN SHAFT
AGGREST LT 2500	S41405N	45	6Q126301	OSCILLATING POST(A)
AGGREST LT 2500	S41405N	46	6Q119101	OSCILLATING POST(B)
AGGREST LT 2500	S41405N	47	6Q118101	STOPPER CAM
AGGREST LT 2500	S41405N	48	6H697801	STOPPER LEVER SPRING
AGGREST LT 2500	S41405N	49	6Q118001	STOPPER LEVER
AGGREST LT 2500	S41405N	50	6Q120301	REAR COVER
AGGREST LT 2500	S41405N	51	6G270801	REAR CAP SCREW
AGGREST LT 2500	S41405N	52	6H595701	OSCILLATING GEAR WASHER
AGGREST LT 2500	S41405N	53	6Q139001	OSCILLATING GEAR
AGGREST LT 2500	S41405N	54	6H770601	OSCILLATING GEAR O-RING
AGGREST LT 2500	S41405N	55	6H129201	OSCILLATING GEAR BEARING WASHER
AGGREST LT 2500	S41405N	56	6G469005	OSCILLATING GEAR BALL BEARING
AGGREST LT 2500	S41405N	57	6Q126101	OSCILLATING GEAR SCREW
AGGREST LT 2500	S41405N	58	6G670501	DRIVE GEAR O-RING
AGGREST LT 2500	S41405N	59	6Q341901	DRIVE GEAR
AGGREST LT 2500	S41405N	60	63758502	DRIVE WASHER
AGGREST LT 2500	S41405N	61	6G467302	DRIVE BALL BEARING
AGGREST LT 2500	S41405N	62	6Q485401	BODY COVER
AGGREST LT 2500	S41405N	63	6G115001	BODY COVER SCREW
AGGREST LT 2500	S41405N	64	6Q485701	HANDLE
AGGREST LT 2500	S41405N	65	6G522706	DRIVE BALL BEARING
AGGREST LT 2500	S41405N	66	6G472401	DRIVE BALL BEARING RING
AGGREST LT 2500	S41405N	67	6F721001	HANDLE COLLAR
AGGREST LT 2500	S41405N	68	61608401	HANDLE SP WASHER
AGGREST LT 2500	S41405N	69	6Q132401	HANDLE SCREW