




AGGREST LT 4000D-C

Feel Alive.



REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
AGGREST LT 4000D-C	S41705N	1	6Q352901	DRAG KNOB
AGGREST LT 4000D-C	S41705N	2	6Q346101	DRAG RING
AGGREST LT 4000D-C	S41705N	3	6J547001	DRAG DISC WASHER
AGGREST LT 4000D-C	S41705N	4	6J546801	DRAG WASHER
AGGREST LT 4000D-C	S41705N	5	6Q346001	DRAG LIP WASHER
AGGREST LT 4000D-C	S41705N	2~6	6Q486801	SPOOL ASSY (2-6)
AGGREST LT 4000D-C	S41705N	7	6E398003	SPOOL WASHER (A)
AGGREST LT 4000D-C	S41705N	8	6Q348502	SPOOL WASHER (B)
AGGREST LT 4000D-C	S41705N	9	6Q457701	CLICK LEAF SPRING
AGGREST LT 4000D-C	S41705N	10	6Q457601	CLICK HOLDER
AGGREST LT 4000D-C	S41705N	11	6Q344001	ROTOR WASHER
AGGREST LT 4000D-C	S41705N	12	6Q122401	ROTOR NUT
AGGREST LT 4000D-C	S41705N	13	6H022701	ROTOR NUT SCREW
AGGREST LT 4000D-C	S41705N	14	6Q351807	ROTOR
AGGREST LT 4000D-C	S41705N	15	6H413601	KICK LEVER SPRING
AGGREST LT 4000D-C	S41705N	16	6Q351901	KICK LEVER
AGGREST LT 4000D-C	S41705N	17	6H417701	KICK LEVER SCREW
AGGREST LT 4000D-C	S41705N	18	6Q129501	ARMLEVER SHAFT
AGGREST LT 4000D-C	S41705N	19	6H576101	ARMLEVER SHAFT PLATE
AGGREST LT 4000D-C	S41705N	20	6H414201	ARMREVER SPRING
AGGREST LT 4000D-C	S41705N	21	6Q121501	ARMLEVER SPRING HOLDER
AGGREST LT 4000D-C	S41705N	22	6Q352101	ARMLEVER SPRING COVER
AGGREST LT 4000D-C	S41705N	23	6G205001	ARMLEVER SPRING COVER SCREW
AGGREST LT 4000D-C	S41705N	24	6Q121606	ARM LEVER
AGGREST LT 4000D-C	S41705N	25	6Q121701	ARMLEVER SCREW COLLER
AGGREST LT 4000D-C	S41705N	26	6G205001	ARMLEVER SCREW
AGGREST LT 4000D-C	S41705N	27	6G195602	ROLLER SCREW
AGGREST LT 4000D-C	S41705N	28	6G195501	ROLLER COLLAR (A)
AGGREST LT 4000D-C	S41705N	29	6G220701	ROLLER COLLAR (B)
AGGREST LT 4000D-C	S41705N	30	6J089903	LINE ROLLER
AGGREST LT 4000D-C	S41705N	31	6Q203401	ROLLER COLLAR (C)
AGGREST LT 4000D-C	S41705N	32	6Q463801	BAIL
AGGREST LT 4000D-C	S41705N	33	-----	-----
AGGREST LT 4000D-C	S41705N	34	6G837101	ONEWAY CLUTCH PLATE SCREW
AGGREST LT 4000D-C	S41705N	35	6Q129001	ONEWAY CLUTCH PLATE
AGGREST LT 4000D-C	S41705N	36	6Q308301	ONEWAY CLUTCH
AGGREST LT 4000D-C	S41705N	37	6J001401	CLUTCH RING
AGGREST LT 4000D-C	S41705N	38	6Q126201	PINION BEARING PLATE SCREW
AGGREST LT 4000D-C	S41705N	39	6H411501	PINION BEARING PLATE
AGGREST LT 4000D-C	S41705N	40	6G535104	PINION BALL BEARING
AGGREST LT 4000D-C	S41705N	41	6Q463501	PINION GEAR
AGGREST LT 4000D-C	S41705N	42	-----	-----
AGGREST LT 4000D-C	S41705N	43	6Q486601	BODY
AGGREST LT 4000D-C	S41705N	44	6Q351001	MAIN SHAFT
AGGREST LT 4000D-C	S41705N	45	6Q126302	OSCILLATING POST(A)
AGGREST LT 4000D-C	S41705N	46	6Q119102	OSCILLATING POST(B)
AGGREST LT 4000D-C	S41705N	47	6Q118101	STOPPER CAM
AGGREST LT 4000D-C	S41705N	48	6H697801	STOPPER LEVER SPRING
AGGREST LT 4000D-C	S41705N	49	6Q118001	STOPPER LEVER
AGGREST LT 4000D-C	S41705N	50	6Q129101	REAR COVER
AGGREST LT 4000D-C	S41705N	51	6G270801	REAR CAP SCREW
AGGREST LT 4000D-C	S41705N	52	6H595701	OSCILLATING GEAR WASHER
AGGREST LT 4000D-C	S41705N	53	6Q350901	OSCILLATING GEAR
AGGREST LT 4000D-C	S41705N	54	6G466001	OSCILLATING GEAR O-RING
AGGREST LT 4000D-C	S41705N	55	6H129201	OSCILLATING GEAR BEARING WASHER
AGGREST LT 4000D-C	S41705N	56	6G469005	OSCILLATING GEAR BALL BEARING
AGGREST LT 4000D-C	S41705N	57	6Q126101	OSCILLATING GEAR SCREW
AGGREST LT 4000D-C	S41705N	58	6G670501	DRIVE GEAR O-RING
AGGREST LT 4000D-C	S41705N	59	6Q351401	DRIVE GEAR
AGGREST LT 4000D-C	S41705N	60	63758502	DRIVE WASHER
AGGREST LT 4000D-C	S41705N	61	6G467302	DRIVE BALL BEARING
AGGREST LT 4000D-C	S41705N	62	6Q486701	BODY COVER
AGGREST LT 4000D-C	S41705N	63	6G115001	BODY COVER SCREW
AGGREST LT 4000D-C	S41705N	64	6Q487001	HANDLE
AGGREST LT 4000D-C	S41705N	65	6G522706	DRIVE BALL BEARING
AGGREST LT 4000D-C	S41705N	66	6G472401	DRIVE BALL BEARING RING
AGGREST LT 4000D-C	S41705N	67	6F721001	HANDLE COLLAR
AGGREST LT 4000D-C	S41705N	68	61608401	HANDLE SP WASHER
AGGREST LT 4000D-C	S41705N	69	6Q132401	HANDLE SCREW