




# AIRD X 2500

Feel Alive.





| REEL NAME   | MGFT CODE | KEY NO | PARTS CODE | DESCRIPTION             |
|-------------|-----------|--------|------------|-------------------------|
| AIRD X 2500 | S2241JD   | 1      | 6Q182201   | Drag Knob               |
| AIRD X 2500 | S2241JD   | 2      | 6F373301   | Drag Washer Retainer    |
| AIRD X 2500 | S2241JD   | 3      | 6E136001   | Drag Washer             |
| AIRD X 2500 | S2241JD   | 4      | 6E467201   | Key Washer              |
| AIRD X 2500 | S2241JD   | 5      | 63733606   | Eared Washer            |
| AIRD X 2500 | S2241JD   | 2~6    | 6Q281401   | Spool Assembly          |
| AIRD X 2500 | S2241JD   | 7      | 6G213001   | "O"-Ring (A)            |
| AIRD X 2500 | S2241JD   | 8      | 6G469005   | Ball Bearing (A)        |
| AIRD X 2500 | S2241JD   | 9      | 6B411706   | Washer (A)              |
| AIRD X 2500 | S2241JD   | 10     | 6E398000   | Washer (B)              |
| AIRD X 2500 | S2241JD   | 11     | 6E467101   | Washer (C)              |
| AIRD X 2500 | S2241JD   | 12     | 6G839301   | Click Gear              |
| AIRD X 2500 | S2241JD   | 13     | 6Q122401   | Rotor Nut               |
| AIRD X 2500 | S2241JD   | 14     | 6H022701   | Screw (A)               |
| AIRD X 2500 | S2241JD   | 15     | 6Q120505   | Rotor                   |
| AIRD X 2500 | S2241JD   | 16     | 6H413601   | Bail Trip Lever Spring  |
| AIRD X 2500 | S2241JD   | 17     | 6Q120701   | Bail Trip Lever         |
| AIRD X 2500 | S2241JD   | 18     | 6H417701   | Screw (B)               |
| AIRD X 2500 | S2241JD   | 19     | 6Q121201   | Bail Spring Shaft       |
| AIRD X 2500 | S2241JD   | 20     | 6H576101   | Retainer                |
| AIRD X 2500 | S2241JD   | 21     | 6H545701   | Bail Spring             |
| AIRD X 2500 | S2241JD   | 22     | 6Q121501   | Bail Spring Holder      |
| AIRD X 2500 | S2241JD   | 23     | 6Q121802   | Cover (A)               |
| AIRD X 2500 | S2241JD   | 24     | 6G270801   | Screw (C)               |
| AIRD X 2500 | S2241JD   | 25     | 6Q121604   | Bail Arm                |
| AIRD X 2500 | S2241JD   | 26     | 6Q121701   | Collar (A)              |
| AIRD X 2500 | S2241JD   | 27     | 6G205001   | Screw (D)               |
| AIRD X 2500 | S2241JD   | 28     | 6G195602   | Screw (E)               |
| AIRD X 2500 | S2241JD   | 29     | 6G195501   | Collar (B)              |
| AIRD X 2500 | S2241JD   | 30     | 6G220701   | Collar (C)              |
| AIRD X 2500 | S2241JD   | 31     | 6J089902   | Line Roller             |
| AIRD X 2500 | S2241JD   | 32     | 6Q203401   | Collar (D)              |
| AIRD X 2500 | S2241JD   | 33     | 6Q281001   | Bail Assembly           |
| AIRD X 2500 | S2241JD   | 34     | -----      | Collar (E)              |
| AIRD X 2500 | S2241JD   | 35     | 6G837101   | Screw (F)               |
| AIRD X 2500 | S2241JD   | 36     | 6Q120101   | Cap                     |
| AIRD X 2500 | S2241JD   | 37     | 6H992901   | Roller Clutch           |
| AIRD X 2500 | S2241JD   | 38     | 6J001401   | Spacing Sleeve          |
| AIRD X 2500 | S2241JD   | 39     | 6Q126201   | Screw (G)               |
| AIRD X 2500 | S2241JD   | 40     | 6H442201   | Bearing Retainer (A)    |
| AIRD X 2500 | S2241JD   | 41     | 6G467302   | Ball Bearing (B)        |
| AIRD X 2500 | S2241JD   | 42     | 6Q132101   | Pinion Gear             |
| AIRD X 2500 | S2241JD   | 43     | 6Q280801   | Body                    |
| AIRD X 2500 | S2241JD   | 44     | 6Q168501   | Main Shaft              |
| AIRD X 2500 | S2241JD   | 45     | 6Q126301   | Stabilizer Bar (A)      |
| AIRD X 2500 | S2241JD   | 46     | 6Q119101   | Stabilizer Bar (B)      |
| AIRD X 2500 | S2241JD   | 47     | 6Q118101   | Anti-Reverse Cam        |
| AIRD X 2500 | S2241JD   | 48     | 6H697801   | Anti-Reverse Cam Spring |
| AIRD X 2500 | S2241JD   | 49     | 6Q118001   | Anti-Reverse Lever      |
| AIRD X 2500 | S2241JD   | 50     | 6Q120302   | Rear Cover              |
| AIRD X 2500 | S2241JD   | 51     | 6G270801   | Screw (H)               |
| AIRD X 2500 | S2241JD   | 52     | 6H595701   | Washer (D)              |
| AIRD X 2500 | S2241JD   | 53     | 6Q118401   | Oscillate Gear          |
| AIRD X 2500 | S2241JD   | 54     | 6H770601   | "O"-Ring (B)            |
| AIRD X 2500 | S2241JD   | 55     | 6H129200   | Washer (E)              |
| AIRD X 2500 | S2241JD   | 56     | 6G469005   | Ball Bearing (C)        |
| AIRD X 2500 | S2241JD   | 57     | 6Q126101   | Screw (I)               |
| AIRD X 2500 | S2241JD   | 58     | 6G670501   | "O"-Ring (C)            |
| AIRD X 2500 | S2241JD   | 59     | 6Q132201   | Drive Gear              |
| AIRD X 2500 | S2241JD   | 60     | 63758500   | Washer (F)              |
| AIRD X 2500 | S2241JD   | 61     | 6G467302   | Ball Bearing (D)        |
| AIRD X 2500 | S2241JD   | 62     | 6Q280901   | Side Cover              |
| AIRD X 2500 | S2241JD   | 63     | 6G115001   | Screw (J)               |
| AIRD X 2500 | S2241JD   | 64     | 6F721001   | Collar (F)              |
| AIRD X 2500 | S2241JD   | 65     | 61608401   | Washer (G)              |
| AIRD X 2500 | S2241JD   | 66     | 6Q132402   | Handle Screw            |
| AIRD X 2500 | S2241JD   | 67     | 6G522702   | Ball Bearing (E)        |
| AIRD X 2500 | S2241JD   | 68     | 6G472401   | Bearing Retainer (B)    |
| AIRD X 2500 | S2241JD   | 69     | 6Q281101   | Handle Assembly         |
| AIRD X 2500 | S2241JD   | 200    | 6H088709   | Handle Knob As          |
| AIRD X 2500 | S2241JD   | 201    | 6G469005   | Ball Bearing            |
| AIRD X 2500 | S2241JD   | 202    | 6B411700   | Washer                  |
| AIRD X 2500 | S2241JD   | 203    | 6B679308   | Truss Head Screw        |
| AIRD X 2500 | S2241JD   | 204    | 6Q281301   | Screw As                |