



Key No.

Key No.	Parts No.	Parts Name
1	740-3801	Drag knob
2	170-4601	Drag washer retainer
3	374-4802	Drag D washer
4	373-3701	Disc washer
5	373-3603	Drag A washer
6	373-3704	Drag washer A
7	733-5405	Spool
8	B07-5302	Spool click claw
9	320-5901	Spool click claw retainer
10	144-1211	Spool click claw spring
11	375-5701	Spool washer
12	720-1721	Spool metal
13	151-7211	Spool metal leaf spring
14	B31-7601	Main shaft
15	637-0102	Oscillating support
16	351-6311	Oscillating slider screw
17	B10-5701	Rotor nut
18	B32-0301	Rotor
19	B18-4701	Bail kick lever spring
20	B32-1801	Bail kick lever
21	B31-7801	Bail kick lever cover
22	351-7701	Bail kick lever cover screw
23	353-8201	Bail holder screw
24	B18-5003	Bail
25	250-4221	Line roller
26	501-1601	Roller collar
27	353-8201	Arm lever screw
28	B18-4501	Arm lever
29	375-1001	Bail washer
30	353-8201	Bail screw
31	Ba8-4401	Bail spring

Key No.

Key No.	Parts No.	Parts Name
32	B32-0201	Bail spring cover
33	351-7701	Bail spring cover screw
34	501-9901	Spring holder
35	145-0901	Anti-reverse claw spring
36	280-9001	Ratchet
37	501-9801	Spacer
38	321-0901	Ball bearing ret. washer
39	351-0901	Ball bearing ret. washer screw
40	635-4801	Ball bearing
41	403-2201	Pinion gear
42	B31-8002	Body
43	B32-1701	Cam kick plate
44	363-2911	Cam kick plate screw
45	111-8201	Anti-reverse claw
46	041-7101	Anti-reverse claw plate
47	363-9301	Anti-reverse claw screw
48	461-7104	Anti-reverse cam
49	144-0321	Anti-reverse cam spring
50	371-6903	Anti-reverse lever washer
51	541-6801	Anti-reverse lever
52	353-4401	Anti-reverse lever screw
53	637-5701	Ball bearing
54	414-1312	Drive gear
55	481-2101	Oscillating slider
56	375-8500	Drive gear washer
57	637-5701	Ball bearing
58	B31-7502	Body cover
59	353-0001	Body cover screw
60	B03-4802	Handle screw cap
61	B56-0801	Handle