


# EMCAST Plus 4500/5000

Please order by parts number, not key number  
Bitte, Best.-Nr. angeben (Nicht "Key"-Nr.)  
Veuillez indiquer le numero de la piece (Non "Key" No.)



**Key No.**

**Parts No.**

**Parts Name**



1	6W3600110	Body Assembly	57	6W3647010	Ball Bearing (G)
2	6W3601010	Washer (A)	58	6W3655010	Washer (G)
3	6W3602010	Handle Screw	59	6W3656010	Bearing Retainer (B)
4	6W3603010	Anti-Reverse Lever	60	6W3657010	Screw (K)
5	6W3604010	Screw (A)	61	6W3658010	Ball Bearing (H)
6	6W3605020	Bearing Retainer (A)	62	6W3659020	Collar (E)
7	6W3606010	Screw (B)	63	6W3660010	Spacing Sleeve
8	6W3607020	Rear Cover (A)	64	6W3661010	Main Shaft Spring (A)
9	6W3608020	Rear Cover (B)	65	6W3662020	Collar (F)
10	6W3609010	Screw (C)	66	6W3658010	Ball Bearing (I)
11	6W3610020	Worm Shaft Retainer (A)	67	6W3663010	Washer (H)
12	6W3611010	Bushing	68	6W3664020	Washer (I)
13	6W3612020	Worm Shaft	69	6W3665010	Main Shaft Spring (B)
14	6W3613020	Ball Bearing (A)	70	6W3666010	Screw (L)
15	6W3614010	Anti-Reverse Cam Spring	71	6W3118010	Washer (J)
16	6W3615020	Stabilizer bar	72	6W3668020	Bail Trip Lever
17	6W3616010	Screw (D)	73	6W3669010	Bail Trip Lever Spring
18	6W3617010	Ball Bearing (B)	74	6W3670010	Bail Spring Holder
19	6W3618020	Oscillating Slider	75	6W3671010	Bail Spring
20	6W3619010	Ball Bearing (C)	76	6W3672020	Bail Spring Shaft
21	6W3620010	Bearing Retainer (B)	77	6W3673020	Cover (A)
22	6W3621020	Oscillating Pawl	78	6W3674010	Screw (M)
23	6W3622020	Collar (A)	79	6W3675010	Screw (N)
24	6W3623010	Washer (B)	80	6W3676010	Screw (O)
25	6W3624020	Oscillating Slider Cover	81	6W3677010	Bail Arm
26	6W3625010	Screw (E)	82	6W3062010	Collar (G)
27	6W3626010	Worm Shaft Retainer (B)	83	6W3061010	Washer (K)
28	6W3627020	Worm Shaft Gear	84	6W3680010	Ball Bearing (J)
29	6W3628020	Ball Bearing (D)	85	6W3681010	Line Roller
30	6W3629010	Anti-Reverse Pawl Spring (A)	86	6W3682020	Bail Assembly
31	6W3630020	Drive Gear	87	6W3683020	Rotor
32	6W3631010	Washer (C)	89	6W3684010	Screw (P)
33	6W3628020	Ball Bearing (E)	90	6W3685020	Cover (B)
34	6W3632020	Side Cover	91	6W3686010	Screw (Q)
35	6W3633010	Screw (F)	92	6W3687020	Rotor Nut
36	6W3634010	Screw (G)	93	6W3688010	Rotor Nut Holding Plate
37	6W3635020	Handle Assembly	94	6W3689010	Screw (R)
38	6W3636020	Anti-Reverse Pawl (A)	95	6W3690020	Main Shaft
39	6W3637020	Collar (B)	96	6W3691020	Line Guard
40	6W3638510	Retainer	97	6W3692010	Click Gear
41	6W3639010	Anti-Reverse Pawl Spring (B)	98	6W3693010	Washer (L)
42	6W3640010	Anti-Reverse Pawl (B)	99-103	6W3694220	Spool Assembly
43	6W3641010	Screw (I)	99-103	6W3694240	Spool Assembly (Extra Spool)
44	6W3642010	Screw (J)	100	6W3696010	Drag Washer
45	6W3643020	Anti-Reverse Cam	101	6W3697010	Key Washer
46	6W3644010	Pinion Retainer	102	6W3698010	Eared Washer
49	6W3647020	Ball Bearing (F)	103	6W3699010	Drag Washer Retainer
50	6W3648020	Pinion Gear	104	6W3695010	Drag Knob
51	6W3649010	Collar (C)			
52	6W3650010	Washer (E)			
53	6W3651010	Roller Clutch			
54	6W3652010	Washer (F)			
55	6W3653010	Collar (D)			
56	6W3654010	Bearing Retainer (A)			

**EMCAST Plus 5000 SPECIAL PARTS**

Key No.	Parts No.	Parts Name
99-103	6W3694320	Spool Assembly
99-103	6W3694340	Spool Assembly (Extra Spool)