


# JUPITER-X3500T / 4000T



**Key No. Parts No. Parts Name**

2-9	F61-1801	SPOOL
1	F32-9506	DRAG KNOB
2	171-7701	DRAG WASHER RET
3	F09-4901	KEY WASHER
4	E13-6003	DRAG WASHER
5	373-3603	EARED WASHER
7	B07-5304	CLICK PAWL
8	E40-3101	CLICK SPRING
9	320-5901	CLICK RET
10	F09-4701	SPOOL WASHER
11	E46-2701	CLICK GEAR
12	F61-9501	MAIN SHAFT
13	F09-1301	OSC SLIDER
14	352-1502	OSC SLIDER SCREW
15	340-6602	ROTOR NUT
16	F31-3904	ROTOR
17	B67-9305	LINE ROLLER SCREW
18	F61-9202	BAIL ARM
19	B84-2102	BAIL ARM SCREW
20	F44-6302	LINE ROLLER COLLAR
21	F44-6202	LINE ROLLER WASHER
22	F47-3401	LINE ROLLER BUSHING
23	F45-4901	LINE ROLLER
24	F61-9802	BAIL
25	E46-2101	BAIL TRIP LEVER
26	F12-8901	BAIL SPRING
27	F31-4312	BAIL SPRING COVER
28	E36-4201	BAIL SPRING COVER SCREW
29	F31-4405	BAIL TRIP COVER
30	E46-2001	SPRING HOLDER

**Key No. Parts No. Parts Name**

31	F31-9801	A/R RATCHET
32	L03-6502	BALL BEARING
33	E48-5201	PINION GEAR
34	F61-1601	BODY
35	E00-7101	A/R PAWL SCREW
36	E46-1302	A/R PAWL
37	E46-1201	A/R PAWL SPRING
38	E03-7801	BEARING RET SCREW
39	F36-5901	A/R CAM SPRING
40	F08-5109	A/R LEVER
41	F13-1601	OSC GEAR COLLAR
42	E46-1501	OSC GEAR
43	E46-7101	DRIVE GEAR
44	373-7802	DRIVE GEAR WASHER
45	F61-1701	SIDE COVER
46	B83-5001	SIDE COVER SCREW A
47	E15-8601	SIDE COVER SCREW B
48	B92-4802	HANDLE LOCK WASHER
49	B92-5004	HANDLE LOCK SCREW
50	L01-1102	HANDLE

**J-X4000T**

**Key No. Parts No. Parts Name**

2-9	F61-2601	SPOOL
16	F31-4204	ROTOR
24	F62-0002	BAIL
25	E48-3101	BAIL TRIP LEVER
34	F61-1603	BODY
45	F61-1703	SIDE COVER