


JUPITER-Z3550 / 4050



RoulementCasting.com

Key No.	Parts No.	Parts Name
1	W00-8501	BODY
2	W00-8601	DRAG WASHER
3	W00-8701	CLICK GEAR
4	W00-8801	KEY WASHER A
5	W00-8901	EARED WASHER
6	W00-9001	KEY WASHER B
7	W00-9101	DRAG COIL SPRING
8	W00-9201	DRAG COLLAR
9	W00-9301	DRAG WASHER SPRING
10	W00-9401	REAR COVER
11	W00-9501	REAR COVER SCREW
12	W00-9601	DRAG KNOB
13	W00-1301	DRAG KNOB SCREW
14	W00-9801	OSC GEAR
15	W00-9901	OSC SLIDER
16	W01-0001	OSC SLIDER RET
17	W01-0101	OSC SLIDER SCREW
18	W01-1202	BALL BEARING A
19	W01-0301	DRIVE GEAR
20	W01-0401	DRIVE GEAR WASHER
21	W01-0501	A/R LEVER
22	W00-2201	A/R LEVER SCREW
23	W01-0701	A/R CAM
24	W00-2401	A/R CAM SPRING
25	W01-0901	A/R PAWL
26	W01-1001	A/R PAWL SCREW
27	W01-1101	A/R PAWL SPRING
28	W01-1201	BALL BEARING B
29	W01-1301	A/R RATCHET
30	W01-1401	SPRING HOLDER
31	W01-1501	BEARING RET SCREW
32	W01-1601	PINION GEAR
33	W00-3301	HANDLE LOCK SCREW
34	W00-3401	CLICK SPRING SCREW
35	W00-3501	COLLAR

Key No.	Parts No.	Parts Name
36	W01-2001	CLICK SPRING
37	W01-2101	SIDE COVER
38	W00-3801	SIDE COVER SCREW A
39	W00-3901	HANDLE COLLAR
40	W01-2401	HANDLE
41	W01-2501	BAIL SPRING
42	W00-4201	BAIL SPRING SHAFT
43	W00-4301	BAIL SPRING HOLDER
44	W01-2801	BAIL TRIP LEVER
45	W01-2901	BAIL SPRING COVER
46	W01-3001	BAIL SPRING COVER SCREW
47	W01-3101	ROTOR
48	W01-3201	ROTOR NUT
49	W01-5501	ROTOR NUT LOCK SCREW
50	W01-6201	SPOOL
50	W01-3403	SPOOL (EXTRA)
51	W01-3501	MAIN SHAFT
52	W01-3601	BAIL
53	W01-6101	LINE ROLLER
54	W00-5501	LINE ROLLER SCREW
55	W01-4001	BAIL ARM
56	W01-4101	BAIL ARM SCREW
57	W01-2201	SIDE COVER SCREW B

J-Z4050 Special Parts

Key No.	Parts No.	Parts Name
14	W01-5001	OSC GEAR
44	W01-6601	BAIL TRIP LEVER
45	W01-6501	BAIL SPRING COVER
47	W01-5101	ROTOR
50	W01-6401	SPOOL
50	W01-6703	SPOOL (EXTRA)
51	W01-5601	MAIN SHAFT
52	W01-5301	BAIL