




Please order by parts number, not key number
 Veuillez indiquer le numéro de la pièce (Non "Key" No.)

SPINNING REEL OPUSBULL 6000H



Key No.	Part No.	Parts Name	Key No.	Part No.	Parts Name
1	W73-3701	Body	43	W57-0801	Bearing Retainer
2	W73-3801	Handle Screw	44	W30-2301	Screw (I)
3	W70-2501	Cover	45	W31-1801	Washer
4	W56-1401	Screw (A)	46	W39-2902	Bail Trip Lever
5	W30-5601	Bushing	47	W31-1701	Bail Trip Lever Spring
6	W30-5501	Oscillating Gear	48	W56-4801	Screw (J)
7	W56-8901	Oscillating Slider	49	W70-4201	Rotor Cover (D)
8	W56-9001	Screw (B)	50	W70-4101	Rotor Cover (C)
9	W70-2701	Ball Bearing (A)	51	W33-9001	Screw (L)
10	W56-9101	Bearing Retainer	52	W73-4001	Rotor
11	W56-9001	Screw (C)	53	W33-9001	Screw (K)
12	W56-9301	Stabilizer bar	54	W57-1101	Rotor Nut
13	W73-3901	Handle Assembly	55	W30-6501	Rotor Nut Holding Plate
14	W56-1901	Screw (E)	56	W30-2301	Screw (N)
15	W56-2001	Screw (D)	57	W56-5201	Bail Spring Holder
16	W70-3001	Side Cover	58	W36-7101	Bail Spring
17	W56-8701	Cover Ring	59	W36-7202	Bail Spring Shaft
18	W42-9301	Ball Bearing (B)	60	W70-3801	Rotor Cover (A)
19	W70-2901	Washer	61	W70-3901	Rotor Cover (B)
20	W70-2801	Drive Gear	62	W56-4801	Screw (J)
21	W56-9701	Spring	63	W36-7601	Screw (M)
22	W70-3201	Rubber Plug	64	W56-5401	Bail Arm
23	W56-9901	Anti-Reverse Pawl	65	W30-6201	Collar (F)
24	W70-3301	Washer	66	W30-6101	Washer
25	W70-3401	Screw (F)	67	W56-5501	Bushing
26	W56-3401	Collar (A)	68	W70-4301	Line Roller
27	W57-0001	Anti-Reverse Lever Spring	69	W73-4101	Bail Assembly
28	W57-0101	Anti-Reverse Pawl	70	W57-1401	Main Shaft
29	W31-6401	Screw (G)	71	W57-1501	Click Gear
30	W70-3501	Pinion Gear	72	W56-6001	Washer
31	W57-0301	Collar (B)	73	W56-6401	Click Pawl
32	W57-0401	Collar (C)	74	W56-6501	Washer
33	OPUSBULL 5000H ONLY		75	W56-6601	Click Pawl Spring
34	W70-3601	Bushing	76-83	W73-4201	Spool Assembly
35	W70-3701	Washer	77	W36-9601	Drag Washer
36	W57-0601	Washer	78	W36-9701	Key Washer
37	W56-4201	Roller Clutch	79	W36-9801	Eared Washer
38	W57-0501	Collar (D)	80	W36-9901	Drag Washer Retainer
39	W56-4301	Collar (E)	81	W56-6301	Line Guard
40	W56-4401	Ball Bearing (C)	82	W56-6201	Washer
41	W56-4501	Bearing Retainer	83	W56-6101	Screw (O)
42	W57-0701	Screw (H)	84	W56-6901	Drag Knob Assembly