


Please order by parts number, not key number
Veuillez indiquer le numéro de la pièce (Non "Key" No.)



SA-Z6500HDF



Key No.	Parts No.	Description	Key No.	Parts No.	Description
1	G34-0603	DRAG KNOB	45	G33-7601	ROTOR BRAKE SPRING
2	F71-0001	DRAG WASHER RET	46	G33-7804	ROTOR BRAKE SPRING COVER
3	G16-5601	DRAG KNOB CLICK PLT	47	G16-1002	ROTOR BRAKE COVER SCREW
4	G16-5801	DRAG WASHER	48	G33-8301	WATER SHIELD
5	G16-5901	EARED WASHER	49	G33-5901	ROTOR CLUTCH COVER
6	G16-2701	KEY WASHER	50	G15-8601	O RING D
7	G15-6801	BALL BEARING H	51	637-6101	BALL BEARING E
2~8	G78-8101	SPOOL ASSEMBLY	52	G33-5801	COLLAR
9	G33-9201	SPOOL METAL	53	F76-5401	ROLLER CLUTCH
10	G33-9301	PIN A	54	G33-5701	SPACING SLEEVE
11	G33-9101	O RING A	55	G15-8101	ROLLER CLUTCH WASHER
12	G33-9401	O RING B	56	E26-2701	A/R RATCHET
13	F21-6101	BALL BEARING A	57	372-7603	RATCHET WASHER
14	G34-1501	SPOOL WASHER	58	G41-7401	PINION GEAR
15	G34-1401	CLICK LEAF SPRING	59	B86-1703	BALL BEARING D
16	G34-1301	CLICK LEAF SPRING HOLDER	60	G33-5501	PINION COLLAR
17	G33-9001	BALL BEARING B	61	G78-7601	BODY
18	G33-8901	MAIN SHAFT PIN	62	G71-6401	BEARING HOLDER SCREW A
19	G33-5101	MAIN SHAFT	63	G33-7001	BODY SHIELD
20	E46-8801	ROTOR NUT HOLD PLATE SCREW	64	G34-3901	A/R CLAW
21	G33-8801	ROTO NUT HOLD PLATE	65	G33-6201	A/R CLAW BUSHING
22	G33-8701	ROTOR NUT SHIELD	66	351-6413	A/R CLAW SCREW
23	F01-6401	BALL BEARING C	67	G33-4901	OSC GEAR A
24	G33-8601	ROTOR NUT	68	G15-7401	OSC GEAR SPRING
25	G33-8501	ROTOR NUT COLLAR	69	G33-4801	OSC GEAR B
26	G33-8401	O RING C	70	G33-5001	OSC GEAR COLLAR
27	E49-2001	ROTOR NUT LOCK SCREW	71	G34-3401	BALL BEARING F
28	G33-7205	ROTOR	72	G34-3501	OSC GEAR SCREW
29	G16-2202	LINE ROLLER SCREW	73	G15-6701	BALL BEARING SHIELD A
30	G16-0605	BAIL ARM	74	G15-6801	BALL BEARING H
31	G16-2001	LINE ROLLER BUSHING	75	G33-4701	OSC PINION GEAR
32	F84-4901	BALL BEARING D	76	G33-6701	OSC GEAR SHIELD
33	G16-2101	LINE ROLLER	77	G33-6601	A/R CLAW SPRING
34	E09-6500	LINE ROLLER WASHER	78	G41-7501	DRIVE GEAR
35	G78-7701	BAIL	79	B27-0700	DRIVE GEAR WASHER A
36	G33-8202	BAIL HOLDER COVER	80	637-6101	BALL BEARING E
37	351-6109	BAIL HOLDER SCREW	81	G33-6901	BALL BEARING SHIELD B
38	G34-1202	BAIL HOLDER NUT	82	G15-9901	BEARING HOLDER SCREW B
39	352-1106	BAIL ARM SCREW	83	G33-6807	BODY COVER
40	G33-7301	BAIL SPRING SHAFT	84	G16-0104	SIDE COVER SCREW
41	G41-8101	BAIL SPRING	85	G33-7101	BODY RING
42	G33-7501	BAIL SPRING HOLDER	86	G34-0004	HANDLE CAP
43	G33-7702	BAIL SPRING COVER	87	G78-7901	HANDLE
44	G16-1002	BAIL SPRING COVER SCREW	88	375-9801	DRIVE GEAR WASHER B