



Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
2-7	G11-6801	SPOOL	37	F62-2201	ROLLER CLUTCH RET
1	F63-2802	DRAG KNOB	38	F62-2001	ROLLER CLUTCH
2	F71-0001	DRAG WASHER RET	39	375-8509	ROLLER CLUTCH WASHER
3	F67-4301	DRAG KNOB CLICK PLT	40	F73-2501	SPACING SLEEVE
4	F69-0901	DRAG WASHER	41	637-5702	BALL BEARING C
5	F67-6401	EARED WASHER	42	F78-1002	PINION COLLAR
6	F67-6301	KEY WASHER	43	F93-5501	PINION GEAR
8	F70-4901	SPOOL CLICK LEAF SPRING	44	F98-4902	BODY
9	E39-4001	SPOOL WASHER	45	F65-1901	A/R LEVER SPRING
10	E12-2303	CLICK LEAF SPRING HOLDER	46	F65-1801	A/R LEVER
11	E36-5301	CLICK GEAR	47	F65-2201	WORM SHAFT BUSH
12	F65-2701	MAIN SHAFT	48	F98-5001	WORM SHAFT
13	341-9203	ROTOR NUT	49	375-4101	WORM SHAFT WASHER
14	B55-7601	ROTOR NUT LOCK SCREW	50	F65-2301	WORM SHAFT COLLAR
15	F92-4902	ROTOR	51	F65-2401	WORM SHAFT RET
16	F92-1701	LINE ROLLER SCREW	52	F65-2601	OSC SLIDER
17	F89-2208	BAIL ARM	53	F89-1701	OSC PAWL
18	F89-7101	LINE ROLLER WASHER	54	F91-3001	OSC PAWL BUSH
19	G02-0801	BALL BEARING A	55	375-0801	OSC PAWL WASHER
20	F92-1601	LINE ROLLER	56	F62-2901	OSC SLIDER COVER
21	G04-7601	LINE ROLLER COLLAR	57	E15-0205	OSC SLIDER COVER SCREW
22	F93-7202	BAIL	58	F65-2902	SHIELD PLT
23	351-7701	BAIL HOLDER SCREW	59	F65-3102	REAR COVER
24	F89-2301	BAIL SPRING SHAFT	60	E24-8101	REAR COVER SCREW
25	E31-3901	BAIL SPRING WASHER	62	F65-2801	DRIVE GEAR
26	F89-2401	BAIL SPRING	63	375-8500	DRIVE GEAR WASHER
27	F89-2603	BAIL SPRING COVER	64	637-5702	BALL BEARING D
28	351-1801	BAIL HOLDER COVER SCREW	65	F65-3007	SIDE COVER
29	F89-3403	BAIL TRIP COVER	66	E15-7502	SIDE COVER SCREW A
30	F62-4701	BAIL TRIP LEVER	67	E13-0501	SIDE COVER SCREW B
31	F62-4601	BAIL TRIP PLT	68	F40-4801	HANDLE COLLAR
32	F92-5801	BEARING RET A	69	363-8511	HANDLE SCREW
33	E24-7402	BEARING RET SCREW	70	F65-3503	HANDLE SCREW CAP
34	F22-6701	BALL BEARING B	71	G12-1601	HANDLE
35	F92-4801	BEARING RET B	72	G04-7901	BAIL HOLDER WASHER
36	F67-5401	BEARING RET C			