


TEAM DAIWA-S3000iA



Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
2-7	F70-5301	SPOOL	37	F73-2201	SPACING SLEEVE
1	F70-5801	DRAG KNOB	38	F64-1101	BALL BEARING C
2	F71-0001	DRAG WASHER RET	39	F26-2801	PINION WASHER
3	F68-1301	DRAG KNOB CLICK PLT	40	F67-9801	PINION GEAR
4	F69-8001	DRAG WASHER	41	F70-5001	BODY
5	F67-6401	EARED WASHER	42	F67-9201	A/R CAM SPRING
6	F68-1101	KEY WASHER	43	F67-9101	A/R LEVER
8	F70-9001	SPOOL CLICK LEAF SPRING	44	F63-1401	WORM SHAFT BUSH
9	E39-7901	SPOOL WASHER	45	F64-0902	WORM SHAFT GEAR
10	F69-7901	CLICK LEAF SPRING HOLDER	46	F64-0802	WORM SHAFT
11	E41-3101	CLICK GEAR	47	375-4101	WORM SHAFT WASHER
12	F68-0001	MAIN SHAFT	48	F67-9501	WORM SHAFT COLLAR
13	340-8604	ROTOR NUT	49	F74-9401	WORM SHAFT RET
14	B55-7801	ROTOR NUT LOCK SCREW	50	F67-9901	OSC SLIDER
15	F64-2506	ROTOR	51	F64-1901	OSC PAWL
16	F62-5201	LINE ROLLER SCREW	52	F62-2701	OSC PAWL BUSH
17	F62-3504	BAIL ARM	53	375-0801	OSC PAWL WASHER
18	F62-5101	BALL BEARING A	54	F62-2901	OSC SLIDER COVER
19	F62-5001	LINE ROLLER	55	352-1502	OSC SLIDER COVER SCREW
20	F71-7501	BAIL	56	F68-0202	SHIELD PLT
21	F69-1101	BAIL SPRING SHAFT	57	F68-0302	REAR COVER
22	F62-3801	BAIL SPRING	58	E36-4202	REAR COVER SCREW
23	F62-3701	BAIL ARM PIN	59	F66-1201	DRIVE GEAR
24	F63-1801	BAIL HOLDER WASHER	60	373-7808	DRIVE GEAR WASHER
25	351-6101	BAIL HOLDER SCREW	61	E15-4001	BALL BEARING D
26	F66-0702	BAIL SPRING COVER	62	F68-0103	SIDE COVER
27	352-2501	BAIL SPRING COVER SCREW	63	E15-7502	SIDE COVER SCREW A
28	F64-6301	BAIL TRIP PLT	64	E15-8602	SIDE COVER SCREW B
29	F62-4701	BAIL TRIP LEVER	65	F43-3502	HANDLE COLLAR
30	F66-0802	BAIL TRIP COVER	66	363-8511	HANDLE SCREW
31	F67-9801	BEARING RET A	67	F64-4001	HANDLE SCREW CAP
32	E24-7402	BEARING RET SCREW	68	F70-5101	HANDLE
33	F64-1601	BALL BEARING B	69	B86-1701	BALL BEARING E
34	F67-9701	BEARING RET B	70	F70-1801	LINE ROLLER COLLAR
35	F64-1401	ROLLER CLUTCH RET	71	F73-2401	COLLAR
36	F64-1201	ROLLER CLUTCH			