


# SPINNING REEL TOURNAMENT-Z3000iT



RoulementCasting.com

Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
2-8	F47-7101	Spool assembly	43	F23-8901	Anti-reverse pawl
1	F44-7301	Drag knob	44	F22-7101	Anti-reverse pawl spring
2	F06-2601	Drag washer retainer	45	351-6601	Bearing retainer screw
3	F01-6001	Click plate washer	46	F25-2901	Ball bearing B
4	E12-2803	Drag knob click plate	47	F26-2801	Spacer
5	B36-0204	Drag washer	48	F36-8401	Pinion gear
6	E15-0101	Eared washer	49	F28-2401	Pinion collar
7	B65-2302	Key washer	50	F47-6501	Body assembly
8	F47-7201	Spool assembly	51	E26-8701	Anti-reverse cam spring
9	F06-2701	Spool washer	52	F01-2712	Anti-reverse lever
10	F47-4901	Main shaft assembly	53	320-5901	Worm shaft gear retainer
11	B74-7702	Spool click leaf spring	54	F02-1301	Worm shaft gear
12	340-6605	Rotor nut	55	F28-2101	Worm shaft bush
13	B66-2603	Rotor nut holding plate	56	E33-2501	Ball bearing C
14	E17-9501	Rotor nut holding plate screw	57	F28-2901	Worm shaft
15	F47-6601	Rotor	58	F28-2602	Worm shield cover
16	F14-2004	Line roller screw	59	F02-0902	Oscillating slider
17	F45-4301	Bail arm	60	F02-1202	Oscillating pawl
18	F34-5901	Bail arm screw	61	E19-1301	Oscillating pawl bush
19	320-5901	Bail arm screw retainer	62	375-0801	Oscillating pawl washer
20	F44-6303	Line roller collar	63	E24-4901	Oscillating slider cover
21	F44-6202	Line roller washer	64	352-1502	Oscillating slider cover screw
22	F45-4902	Line roller	65	375-4101	Worm shaft washer
23	F05-5601	Ball bearing A	66	F28-2201	Ball bearing D
24	F47-6701	Bail assembly	67	F28-2301	Worm shaft retainer
25	E12-4701	Bail spring shaft	68	F28-2401	Worm shaft collar
26	E31-3901	Bail spring washer	69	F01-6102	Water shield
27	E43-5401	Bail spring	70	F01-6212	Rear cover
28	F35-5403	Bail spring cover	71	F01-6302	Rear cover screw A
29	F01-3703	Bail spring cover screw	72	F01-7202	Rear cover screw B
30	F35-5701	Bail trip plate	73	B68-1701	Ball bearing E
31	F49-9201	Bail trip lever	74	F02-1602	Drive gear
32	F35-5803	Bail trip cover	75	373-7808	Drive gear washer
33	F19-7302	Oiled washer	76	B62-8601	Ball bearing F
34	F18-2901	Roller clutch	77	F02-1804	Side cover
35	F25-6301	Roller clutch retainer	78	351-1106	Side cover screw
36	353-0001	Roller clutch screw	79	F43-3502	Handle collar
37	F25-3001	Spacing sleeve	80	F04-5002	Handle screw
38	F23-9102	Anti-reverse ratchet	81	F24-6202	Handle screw cap
39	F23-8303	Bearing retainer	82	F50-2802	Handle assembly
40	F22-6801	Anti-reverse pawl collar	83	F23-8701	Anti-reverse pawl collar
41	F23-8802	Anti-reverse pawl plate			
42	E45-4001	Anti-reverse pawl screw			