



KEY NO.	PARTS NAME	KEY NO.	PARTS NAME	KEY NO.	PARTS NAME	KEY NO.	PARTS NAME	KEY NO.	PARTS NAME	KEY NO.	PARTS NAME	KEY NO.	PARTS NAME
1	FRAME	16	WORM SHAFT WASHER	30	E-RING	44	DRIVE GEAR	58	CLICKER	74	CLICKER	90	PIN
2	CLUTCH BAR PLATE (A)	17	E-RING	31	BEARING PLATE SCREW	45	DRAG WASHER (L*3)	59	CLICK PLATE	75	CLICK PLATE	91	BRAKE HOLDER
3	CLUTCH BAR PLATE (B)	18	PILLAR	32	YOKE HOLDER	46	DRAG WASHER (D1)	60	CLICK PLATE RETAINER	76	CLICK PLATE RETAINER	92	BRAKE SHOE (*4)
4	CLUTCH BAR	19	LEVEL WIND PIN	33	CLUTCH CAM	47	DRAG WASHER (A)	61	TENSION WASHER	77	HANDLE WASHER	93	BRAKE SHOE SPRING (*4)
5	CLUTCH LINK	20	SPACER(OPTIONAL)	34	CLUTCH SPRING	48	DRAG WASHER (D2)	62	SPOOL SPACER (B)	78	HANDLE ASSEMBLY	94	MAGNET PLATE
6	CLUTCH BAR SCREW	21	LEVEL WIND NUT	35	KICK LEVER	49	SLEEVE WASHER (OPTIONAL)	63	LOCKING PIN	79	BALL BEARING (*2)	95	MAGNET PLATE SCREW (*2)
7	LEVEL WIND ASSEMBLY	22	FRONT COVER	36	KICK LEVER SPRING	50	SLEEVE	64	E-RING	80	HANDLE KNOB ASSEMBLY (*2)	96	PALM SIDE COVER ASSEMBLY
8	PIPE	23	FRONT COVER SCREW (*2)	37	CAM PLATE	51	GEAR SIDE COVER ASSEMBLY	65	LOCKING PIN SPRING	81	BALL BEARING (*2)	97	PALM SIDE COVER TRIM
9	WORM SHAFT	24	BALL BEARING	38	CAM PLATE SCREW (*2)	52	GEAR SIDE COVER TRIM	66	GEAR SIDE COVER SCREW (A)	82	HANDLE KNOB SCREW (*2)	98	CONTROL DIAL ASSEMBLY
10	BALL BEARING	25	CRANK SHAFT	39	PINION YOKE	53	ONE WAY CLUTCH	67	GEAR SIDE COVER SCREW (B)	83	HANDLE KNOB CAP (*2)	99	SPOOL COVER
12	IDLER (S)	26	IDLER (L) WASHER (A)	40	PINION GEAR	54	O-RING	68	GEAR SIDE COVER SCREW (C)	84	HANDLE WASHER	100	MAGNET HOLDER
13	WORM SHAFT PIN	27	IDLER (L)	41	PINION YOKE SPRING (*2)	55	BALL BEARING	71	DRAG SPRING WASHER (*2)	85	HANDLE NUT	101	MAGNET HOLDER PLATE
14	BALL BEARING	28	IDLER (L) WASHER (B)	42	RATCHET	56	C-RING	72	CLICK HOLDER	86	HANDLE NUT RETAINER	102	MAGNET (*5)
15	WORM SHAFT BUSHING (B)	29	BEARING PLATE	43	RATCHET WASHER	57	CAST CONTROL CAP	73	STAR DRAG ASSEMBLY	87	HANDLE NUT RETAINER SCREW	103	MAGNET HOLDER SPRING (*2)
										88	SPOOL ASSEMBLY	104	SLIDE CAM
										89	BALL BEARING	105	SPOOL COVER SCREW (*3)
												106	SPOOL SPACER
												107	BALL BEARING
												108	BEARING RETAINER