



**CS 401A** 

| BNT No. | PARTS NAMES               | BNT No. | PARTS NAMES            | BNT No. | PARTS NAMES              |
|---------|---------------------------|---------|------------------------|---------|--------------------------|
| 0042    | Line Guide Pawl           | 1853    | Key Washer (A)         | 2087    | Quick-Fire II Clutch Bar |
| 0133    | "E" Lock                  | 1854    | Eared Washer (B-1)     | 2092    | Click Plate              |
| 0191    | Clutch Bar Support Screw  | 1921    | Cast Control Cap       | 2093    | Click Switch Spring      |
| 0194    | Ball Bearing              | 1922    | Cast Control Spacer    | 2094    | Click Switch             |
| 0425    | "E" Lock                  | 1927    | Anti-Reverse Ratchet   | 2095    | Click Pawl               |
| 0609    | Multi-Purpose Screw       | 1930    | Clutch Cam Screw       | 2097    | Worm Bushing (A)         |
| 0664    | Spacer B                  | 1937    | Line Guide Assembly    | 2238    | Bush Plate Screw         |
| 0686    | "E" Lock                  | 1940    | Frame Nut              | 2242    | Roller Clutch Inner Tube |
| 0770    | Handle Nut Plate Screw    | 1941    | Stand Screw            | 2291    | Handle Assembly          |
| 0799    | Friction Washer           | 1948    | Brake Collar           | 2293    | Left Side Plate Nut      |
| 0816    | Shaft Washer              | 1949    | Right Side Plate Screw | 2298    | Drive Shaft Washer (B)   |
| 0819    | Drive Shaft Bushing       | 1957    | Worm Bushing (B)       | 2305    | Stand Bolt               |
| 0830    | Spacer (optional)         | 1962    | Thumb Rest             | 2312    | Right Side I.D. Plate    |
| 1133    | Yoke Spring               | 1963    | Level Wind Guard       | 2314    | Frame Bar                |
| 1201    | Retractor Spring Collar   | 1965    | Idle Gear (A)          | 2315    | Spool Assembly           |
| 1227    | Push Nut (SPN-2)          | 1966    | Stand                  | 2316    | Clutch Bar Support       |
| 1239    | Pawl Cap                  | 1968    | Idle Gear (B) Shaft    | 2324    | Star Drag                |
| 1245    | Clutch Bar Support Spacer | 1969    | Idle Gear (B)          | 2326    | Roller Clutch Assembly   |
| 1354    | Click Switch Screw        | 1971A   | Worm Shaft             | 2327    | Return Pin Guide         |
| 1455    | Drag Spring Washer (H)    | 1972    | Click Spring           | 2328    | Drive Gear               |
| 1472    | Anti-Reverse Pawl         | 1974    | Click Switch Washer    | 2329    | Drive Shaft              |
| 1613    | Drag Spring Washer (L)    | 1976    | Click Shaft            | 2330    | Clutch Cam               |
| 1616    | Left Side Plate Screw     | 2050    | Clutch Cam Retainer    | 2331    | Clutch Pawl              |
| 1618    | Key Washer (C)            | 2076    | Pinion Gear            | 2332    | A-Side Seal              |
| 1620    | Eared Washer              | 2077    | Yoke                   | 2333    | Set Plate                |
| 1692    | Handle Nut Plate          | 2078    | Retractor Spring       | 2334    | Left Side Frame          |
| 1697    | Spool Tension Spring      | 2081    | Clutch Pawl Spring     | 2337    | Left Side Plate          |
| 1788    | Handle Nut                | 2083    | Clutch Plate           | 2338    | Right Side Frame         |
| 1851    | Drag Washer (C)           | 2085    | Brake Case             | 2339    | B-Side Seal              |
| 1852    | Drag Washer (B-2)         | 2086    | Clutch Bar Guide       | 2340    | Right Side Plate         |