




SPIREX 2000RB

00

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0026	Ball Bearing	3471	Anti-Reverse Cam Spring	4366	Bail Arm
0041	Drive Gear Washer	3656	Anti-Reverse Ratchet	4421	Handle Screw Cap
0050	Anti-Reverse Lever Screw	3658	Anti-Reverse Pawl	4535	Double Paddle Handle Assembly
0071	Rotor Nut	3659	Anti-Reverse Pawl Spring	4546	Pressure Screw
0540	Multi-Purpose Screw	3673	Oscillating Gear	5190	Anti-Reverse Lever
0582	"O" Ring	3742	Drive Gear	5461	Bail Spring Cover
0642	Side Cover Screw	3743	Hold Click Spring	5464	Pinion Gear
0779	Bail Hold Support Screw	3745	Oscillating Slider	5465	Anti-Reverse Cam
0786	Trigger Screw	3746	Oscillating Slider Retainer	5469	Rotor
0787	Nut Lock Screw	3747	Slider Retainer Screw	5471	Bail Trip Lever
0792	Bearing Retainer Screw	3749	Drag Washer "C" (white)	5472	Counterbalance Cover
0930	Ball Bearing	3750	Eared Washer "B"	5503	Main Shaft
1008	Handle Lock Washer	3751	Drag Washer "C" (blue)	5504	Side Cover
1890	Bushing Washer	3754	Drag Spring Washer	5505	Drag Shaft (A)
1891	Bail Spring Cover Screw	3775	Drag Click	5506	Drag Shaft (B)
1974	Drag Coil Spring	3776	Drag Washer "C" (cloth)	5507	Fightin' Drag Lever
2280	Anti-Reverse Lock Out	3777	Click Gear	5508	Drag Programmer
2283	Anti-Reverse Pawl Screw	3778	Eared Washer "Br"	5510	Spool Assembly (aluminum)
2852	Handle Screw Lock	3781	Lever Click Gear	5511	Spool Assembly (graphite)
3125	Drag Click Screw	3782	Fightin' Pressure Screw Washer	5512	Body
3306	Line Roller Bearing	3783	Fightin' Pressure Screw	5625	Line Roller Spacer
3309	Line Roller Screw	3785	Lever Hold Spring	5630	Line Roller
3396	Bail Spring Guide (A)	3787	Drag Programmer Screw	5909	Line Roller Bushing
3397	Bail Spring	3869	Anti-Reverse Lock Out Spring	6622	Line Roller Washer
3398	Bail Spring Guide (B)	4160	Trigger Cam	6623	Bearing Spacer
3402	Cover Screw	4364	Quick-Fire II Trigger	6632	Bail Assembly

(110830)