


# SYMETRE



1000FG 00

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0041	Drive Gear Washer	6018	Ball Bearing	6482	Protector Screw
0071	Rotor Nut	6033	Bail Trip Lever	6483	Bail Hold Support Spacer
0647	Worm Shaft Retainer Screw	6035	Line Roller	6484	Bail Assembly
0786	Bail Arm Screw	6040	Roller Clutch Assembly	6486	Roller Clutch Screw
0806	Bail Hold Support Screw	6042	Friction Ring	6487	Adjusting Washer
0930	Ball Bearing	6060	Oscillating Slider Bushing	6489	Anti-Reverse Cam
1008	Handle Lock Washer	6077	Click Pin	6490	Worm Bushing (front)
1520	Anti-Reverse Cam Spring	6092	Idle Gear	6493	Worm Bushing (rear)
2298	Spacer	6099	Oscillating Pawl Cover	6500	Oscillating Slider
2852	Handle Screw Lock	6100	Oscillating Pawl	6501	Worm Shaft Retainer
2934	Multi-Purpose Screw	6289	Nut Lock Screw	6502	Oscillating Guide
3366	Anti-Reverse Lever Screw	6290	Rotor Nut Lock Plate	6573	Anti-Reverse Lever
3455	Spool Washer	6293	Line Roller Bushing	6589	Spool Assembly
3456	Spool Support	6294	Line Roller Spacer	6590	Rotor
3481	Bushing	6295	Line Roller Washer	6592	Worm Shaft
4150	Rear Protector Screw	6296	Click Spring	6593	Drive Gear
4421	Handle Screw Cap	6297	Bail Spring Guide (A)	6594	Side Cover
4450	Handle Assembly	6298	Bail Spring	6595	Side Cover Flange
4675	Oscillating Pawl Cover Screw	6299	Bail Spring Guide (B)	6596	Side Cover Screw (short)
4680	Slider Retainer Screw	6300	Bail Spring Cover	6597	Side Cover Screw (long)
4716	Lever Spring Guide (B)	6302	Line Roller Screw	6598	Body
4717	Lever Spring	6305	Rotor Protector	6671	Bail Arm
4718	Lever Spring Guide (A)	6306	Trip Lever Spacer	6672	Rear Protector
4838	Drive Gear Bushing	6307	Bail Hold Support Shaft	7282	Pinion Gear
5180	Drag Knob	6479	Main Shaft		