



4000FA 00

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0026	Ball Bearing	3452	Spool Assembly (graphite)	3869	Anti-Reverse Lock Out Spring
0041	Drive Gear Washer	3503	Spool Washer	4161	Trigger Cam
0050	Anti-Reverse Lever Screw	3665	Slider Retainer Screw	4362	Side Cover Screw (large)
0071	Rotor Nut	3677	Main Shaft	4367	Line Roller Screw
0540	Multi-Purpose Screw	3681	Bail Spring Guide (A)	4373	Quick-Fire II Trigger
0642	Side Cover Screw (small)	3682	Bail Spring	4375	Bail Arm
0779	Bail Hold Support Screw	3683	Bail Spring Guide (B)	4421	Handle Screw Cap
0786	Trigger Screw	3685	Bail Trip Lever	4890	Anti-Reverse Lever
0787	Nut Lock Screw	3687	Anti-Reverse Ratchet	4897	Drag Knob
0792	Bearing Retainer Screw	3688	Anti-Reverse Lock Out	4898	Spool Assembly (aluminum)
0930	Ball Bearing	3689	Bushing Washer	4930	Side Cover Flange
1008	Handle Lock Washer	3690	Pinion Gear	4931	Side Cover
1511	Lever Spring	3691	Anti-Reverse Pawl	4932	Body
1520	Anti-Reverse Cam Spring	3692	Anti-Reverse Pawl Spring	5548	Handle Assembly
2293	Drive Gear Bushing	3693	Anti-Reverse Cam	5625	Line Roller Spacer
2516	Spool Support	3694	Drive Gear	5628	Line Roller Collar
2541	Anti-Reverse Pawl Screw	3695	Oscillating Gear	5629	Line Roller Bushing
2852	Handle Screw Lock	3696	Oscillating Slider	5630	Line Roller
2934	Flange Screw	3710	Rotor	6735	Bail Assembly
3359	Line Roller Washer	3712	Bail Spring Cover		
3402	Cover Screw	3713	Counterbalance Cover		