



AXULSA 01

| RD No. | PARTS NAMES | RD No. | PARTS NAMES | RD No. | PARTS NAMES |
|--------|--------------------------|--------|-----------------------|--------|------------------------------|
| 0013 | Lever Spring | 0948 | Bail Trip Cover Screw | 1439 | Drive Gear |
| 0018 | Line Roller | 1004 | Bushing (A) | 1440 | Oscillating Arm |
| 0026 | Ball Bearing | 1007 | Lock Washer Retainer | 1442 | Handle Screw Cap |
| 0049 | Lock Washer | 1008 | Handle Lock Washer | 1443 | Oscillating Block |
| 0053 | Anti-Reverse Cam Spring | 1083 | Slider Retainer Screw | 1444 | Anti-Reverse Cam |
| 0071 | Rotor Nut | 1302 | Line Roller Screw | 1445 | Anti-Reverse Lever |
| 0345 | Anti-Reverse Lever Screw | 1418 | Drag Knob | 1446 | Handle Assembly |
| 0539 | Anti-Reverse Pawl Spring | 1425 | Main Shaft | 1883A | Anti-Reverse Lock Out |
| 0540 | Anti-Reverse Pawl Screw | 1427 | Spool Support | 1884A | Anti-Reverse Lock Out Spring |
| 0543 | Side Cover Screw | 1428 | Rotor | 1885A | Pinion Spacer |
| 0781 | Bail Spring | 1429 | Bail Assembly | 1886 | Bail Trip Lever Screw |
| 0784 | Line Roller Washer | 1430 | Bail Trip Cover | 1927 | Spool Washer |
| 0787 | Nut Lock Screw | 1431 | Bail Spring Cover | 4142 | Spool Assembly |
| 0792 | Bearing Retainer Screw | 1432 | Bail Arm | 6781 | Drive Gear Washer |
| 0795 | Bushing (B) | 1433 | Bail Trip Lever | 7106 | Body |
| 0884 | Anti-Reverse Ratchet | 1437 | Pinion Gear | 7107 | Side Cover |
| 0940 | Bail Trip Cam Screw | 1438 | Anti-Reverse Pawl | | |