



2000R 01

| RD No. | PARTS NAMES | RD No. | PARTS NAMES | RD No. | PARTS NAMES |
|--------|--------------------------|--------|-----------------------------|--------|------------------------------|
| 0041 | Drive Gear Washer | 2257 | Drag Washer "H" (blue) | 4097 | Pressure Screw |
| 0050 | Anti-Reverse Lever Screw | 2283 | Anti-Reverse Pawl Screw | 4098 | Drag Knob |
| 0080 | Line Roller | 2293 | Drive Gear Bushing | 4099 | Drag Knob Screw |
| 0111 | Drag Coil Spring | 2852 | Handle Screw Lock | 4295 | Bail Spring Guide (B) |
| 0452 | Drag Spring Washer | 3455 | Spool Washer | 4299 | Anti-Reverse Cam |
| 0540 | Drag Click Screw | 3471 | Anti-Reverse Cam Spring | 4367 | Line Roller Screw |
| 0574 | Drag Washer "C" (cloth) | 3673 | Oscillating Gear | 4379 | Anti-Reverse Lever |
| 0579 | Eared Washer "B" | 3744 | Drag Click | 4388 | Bail Arm |
| 0584 | Hold Click Spring | 3745 | Oscillating Slider | 5583 | Anti-Reverse Lock Out Spring |
| 0642 | Side Cover Screw | 3746 | Oscillating Slider Retainer | 5584 | Anti-Reverse Lock Out |
| 0779 | Multi-Purpose Screw | 3747 | Slider Retainer Screw | 5591 | Bail Spring Cover |
| 0815 | Line Roller Washer | 3848 | Bail Spring Guide (A) | 5594 | Bail Trip Lever |
| 1008 | Handle Lock Washer | 3856 | Anti-Reverse Pawl | 5595 | Counterbalance Cover |
| 1025 | Handle Assembly | 3857 | Anti-Reverse Pawl Spring | 5614 | Bail Assembly |
| 1442 | Handle Screw Cap | 4051 | Bail Spring | 7247 | Side Cover |
| 1514 | Bushing Washer | 4084 | Main Shaft | 7249 | Spool Assembly |
| 1515 | Bushing | 4085 | Spool Support | 7256 | Rotor Assembly |
| 1891 | Multi-Purpose Screw | 4095 | Drive Gear | 7257 | Body |
| 1951 | Rotor Lock | 4096 | Drag Shaft | | |