



4000R 01

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0041	Drive Gear Washer	2257	Drag Washer "H" (blue)	4274	Drag Shaft
0050	Anti-Reverse Lever Screw	2293	Drive Gear Bushing	4275	Drag Knob
0080	Line Roller	2346	Drag Washer "C" (cloth)	4308	Anti-Reverse Pawl
0111	Drag Coil Spring	2433	Pressure Screw	4309	Anti-Reverse Cam
0452	Drag Spring Washer	2541	Anti-Reverse Pawl Screw	4310	Drag Click
0540	Multi-Purpose Screw	2852	Handle Screw Lock	4317	Bail Spring Cover
0579	Eared Washer "B"	3681	Bail Spring Guide (A)	4318	Bail Trip Lever
0584	Hold Click Spring	3682	Bail Spring	4362	Side Cover Screw
0779	Multi-Purpose Screw	3695	Oscillating Gear	4367	Line Roller Screw
0815	Line Roller Washer	3747	Slider Retainer Screw	4379	Anti-Reverse Lever
0826	Key Washer "A"	3766	Oscillating Slider	4392	Bail Arm
1008	Handle Lock Washer	3767	Oscillating Slider Retainer	4398	Bail Assembly
1030	Handle Assembly	3794	Drag Knob Screw	5600	Anti-Reverse Lock Out Spring
1442	Handle Screw Cap	3873	Anti-Reverse Pawl Spring	7252	Spool Assembly
1511	Lever Spring	4259	Spool Washer	7254	Side Cover
1520	Anti-Reverse Cam Spring	4260	Spool Support	7258	Rotor Assembly
1951	Rotor Lock	4261	Main Shaft	7259	Anti-Reverse Lock Out
1957	Bushing Washer	4264	Bail Spring Guide (B)	7260	Body
1958	Bushing	4267	Bail Trip Lever Washer		
2016	Drag Washer "H" (cloth)	4272	Drive Gear		