



EX1000RA 01

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0026	Ball Bearing	1596	Bushing Washer	3746	Oscillating Slider Retainer
0041	Drive Gear Washer	2257	Drag Washer "H" (blue)	3747	Slider Retainer Screw
0071	Rotor Nut	2280	Anti-Reverse Lock Out	3869	Anti-Reverse Lock Out Spring
0111	Drag Coil Spring	2283	Anti-Reverse Pawl Screw	4051	Bail Spring
0345	Anti-Reverse Lever Screw	2293	Drive Gear Bushing	4093	Anti-Reverse Cam
0452	Drag Spring Washer	2852	Handle Screw Lock	4096	Drag Shaft
0540	Drag Click Screw	2857	Trigger Cam	4097	Pressure Screw
0543	Side Cover Screw	3359	Line Roller Washer	4099	Drag Knob Screw
0574	Drag Washer "C" (cloth)	3400	Bail Trip Lever	4111	Pinion Gear
0579	Eared Washer "B"	3471	Anti-Reverse Cam Spring	4112	Drive Gear
0584	Hold Click Spring	3647	Rotor	4287	Drag Knob Assembly
0787	Nut Lock Screw	3651	Bail Spring Guide (A)	4348	Quick-Fire II Trigger
0792	Bearing Retainer Screw	3652	Bail Spring Guide (B)	4350	Bail Arm
0930	Ball Bearing	3653	Bail Spring Cover	4379	Anti-Reverse Lever
0940	Bail Hold Support Screw	3654	Counterbalance Cover	5625	Line Roller Spacer
0949	Trigger Screw	3655	Cover Screw	5628	Line Roller Collar
1008	Handle Lock Washer	3656	Anti-Reverse Ratchet	5629	Line Roller Bushing
1025	Handle Assembly	3658	Anti-Reverse Pawl	5630	Line Roller
1310	Line Roller Screw	3659	Anti-Reverse Pawl Spring	6730	Bail Assembly
1442	Handle Screw Cap	3663	Oscillating Gear	6853	Spool Assembly
1504	Bail Spring Cover Screw	3744	Drag Click	7050	Main Shaft Assembly
1506	Multi-Purpose Screw	3745	Oscillating Slider	7051	Body Set

(120630)