



RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0041	Drive Gear Washer	3455	Spool Washer	5583	Anti-Reverse Lock Out Spring
0050	Anti-Reverse Lever Screw	3471	Anti-Reverse Cam Spring	5584	Anti-Reverse Lock Out
0080	Line Roller	3645	Drag Knob	5585	Rotor Lock
0642	Side Cover Screw	3665	Slider Retainer Screw	5586	Pinion Bushing (back)
0779	Multi-Purpose Screw	3673	Oscillating Gear	5587	Drive Gear
0815	Line Roller Washer	3848	Bail Spring Guide (A)	5591	Bail Spring Cover
1008	Handle Lock Washer	3856	Anti-Reverse Pawl	5592	Bail Assembly
1025	Handle Assembly	3857	Anti-Reverse Pawl Spring	5593	Rotor Assembly
1427	Spool Support	3858	Anti-Reverse Cam	5594	Bail Trip Lever
1442	Handle Screw Cap	4051	Bail Spring	5595	Counterbalance Cover
1514	Bushing Washer	4295	Bail Spring Guide (B)	5791	Bushing
1891	Multi-Purpose Screw	4351	Anti-Reverse Lever	5793	Oscillating Slider
2283	Anti-Reverse Pawl Screw	4367	Line Roller Screw	6847	Spool Assembly
2293	Drive Gear Bushing	4388	Bail Arm	6848	Side Cover
2852	Handle Screw Lock	5581	Main Shaft	6849	Body