



**FX4000FA** 01

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0041	Drive Gear Washer	2852	Handle Screw Lock	4367	Line Roller Screw
0050	Anti-Reverse Lever Screw	3503	Spool Washer	4392	Bail Arm
0080	Line Roller	3665	Slider Retainer Screw	5177	Bail Assembly
0540	Multi-Purpose Screw	3676	Drag Knob	5599	Rotor Assembly
0642	Side Cover Screw (small)	3677	Main Shaft	5600	Anti-Reverse Lock Out Spring
0779	Multi-Purpose Screw	3681	Bail Spring Guide (A)	5601	Anti-Reverse Lock Out
0815	Line Roller Washer	3682	Bail Spring	5602	Anti-Reverse Pawl
1008	Handle Lock Washer	3695	Oscillating Gear	5603	Rotor Lock
1030	Handle Assembly	3874	Anti-Reverse Cam	5604	Pinion Bushing (back)
1442	Handle Screw Cap	4264	Bail Spring Guide (B)	5605	Drive Gear
1511	Lever Spring	4267	Bail Trip Lever Washer	5646	Anti-Reverse Pawl Spring
1520	Anti-Reverse Cam Spring	4317	Bail Spring Cover	5792	Bushing
1957	Bushing Washer	4318	Bail Trip Lever	5794	Oscillating Slider
2293	Drive Gear Bushing	4351	Anti-Reverse Lever	6850	Spool Assembly
2516	Spool Support	4360	Side Cover Flange	6851	Side Cover
2541	Anti-Reverse Pawl Screw	4362	Side Cover Screw (large)	6852	Body