



SX 3000 01

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0026	Ball Bearing	4649	Spacer	5207	Anti-Reverse Cam
0041	Drive Gear Washer	4650	Bail Hold Support Shaft	5208	Anti-Reverse Lever
0050	Anti-Reverse Lever Screw	4652	Lever Spring Guide (B)	5209	Drive Gear
0071	Rotor Nut	4653	Lever Spring	5212	Oscillating Slider
0787	Nut Lock Screw	4654	Lever Spring Guide (A)	5213	Oscillating Gear
1008	Handle Lock Washer	4656	Trip Lever Spacer	5560	Handle Assembly
1506	Clutch Cover Screw	4661	Anti-Reverse Cam Ring	5625	Line Roller Spacer
1520	Anti-Reverse Cam Spring	4698	Bail Spring Guide (A)	5628	Line Roller Collar
1891	Bail Hold Support Guard Screw	4699	Bail Spring	5629	Line Roller Bushing
2293	Drive Gear Bushing	4700	Bail Spring Guide (B)	5630	Line Roller
2404	"E" Lock	4701	Bail Arm Screw	6606	Side Cover Screw (short)
2516	Spool Support	4702	Bail Arm Bushing	6652	Bail Assembly
2852	Handle Screw Lock	4714	Roller Clutch Assembly	6829	Spool Assembly
3309	Line Roller Screw	4823	Bail Arm	6830	Bail Hold Support Guard
3359	Line Roller Washer	4826	Bail Hold Support Spacer	6831	Rotor
3402	Bail Spring Cover Screw (small)	4829	Roller Clutch Screw	6832	Bail Spring Cover
3503	Spool Washer	4972	Bail Trip Lever	6833	Body Assembly
3665	Slider Retainer Screw	5199	Drag Knob	7665	Bail Spring Cover Screw (large)
4362	Side Cover Screw (long)	5201	Main Shaft		
4421	Handle Screw Cap	5206	Pinion Gear		