



SX 4000 01

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0026	Ball Bearing	4649	Spacer	5203	Bail Hold Support Guard
0041	Drive Gear Washer	4650	Bail Hold Support Shaft	5206	Pinion Gear
0050	Anti-Reverse Lever Screw	4652	Lever Spring Guide (B)	5207	Anti-Reverse Cam
0071	Rotor Nut	4654	Lever Spring Guide (A)	5208	Anti-Reverse Lever
0787	Nut Lock Screw	4656	Trip Lever Spacer	5209	Drive Gear
1008	Handle Lock Washer	4661	Anti-Reverse Cam Ring	5212	Oscillating Slider
1506	Clutch Cover Screw	4698	Bail Spring Guide (A)	5213	Oscillating Gear
1520	Anti-Reverse Cam Spring	4699	Bail Spring	5548	Handle Assembly
1891	Bail Hold Support Guard Screw	4700	Bail Spring Guide (B)	5625	Line Roller Spacer
2293	Drive Gear Bushing	4701	Bail Arm Screw	5628	Line Roller Collar
2404	"E" Lock	4702	Bail Arm Bushing	5629	Line Roller Bushing
2516	Spool Support	4710	Lever Spring	5642	Line Roller
2852	Handle Screw Lock	4711	Bail Trip Lever	6606	Side Cover Screw (short)
3309	Line Roller Screw	4714	Roller Clutch Assembly	6825	Spool Assembly
3359	Line Roller Washer	4823	Bail Arm	6826	Bail Assembly
3402	Bail Spring Cover Screw (small)	4826	Bail Hold Support Spacer	6827	Rotor
3503	Spool Washer	4829	Roller Clutch Screw	6828	Body Assembly
3665	Slider Retainer Screw	5199	Drag Knob	7665	Bail Spring Cover Screw (large)
4362	Side Cover Screw (long)	5201	Main Shaft		
4421	Handle Screw Cap	5202	Bail Spring Cover		