


SIDESTAB 1000RD 01



RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0026	Ball Bearing	2283	Anti-Reverse Pawl Screw	4099	Drag Knob Screw
0041	Drive Gear Washer	2852	Handle Screw Lock	4111	Pinion Gear
0050	Anti-Reverse Lever Screw	3359	Line Roller Washer	4112	Drive Gear
0071	Rotor Nut	3400	Bail Trip Lever	4160	Trigger Cam
0111	Drag Coil Spring	3402	Cover Screw	4364	Quick-Fire II Trigger
0452	Drag Spring Washer	3471	Anti-Reverse Cam Spring	4366	Bail Arm
0540	Multi-Purpose Screw	3651	Bail Spring Guide (A)	4367	Line Roller Screw
0574	Drag Washer "C" (cloth)	3652	Bail Spring Guide (B)	4421	Handle Screw Cap
0579	Eared Washer "B"	3656	Anti-Reverse Ratchet	4906	Anti-Reverse Lever
0584	Hold Click Spring	3658	Anti-Reverse Pawl	4940	Drag Knob Assembly
0642	Side Cover Screw	3659	Anti-Reverse Pawl Spring	5547	Handle Assembly
0779	Bail Hold Support Screw	3663	Oscillating Gear	5625	Line Roller Spacer
0786	Trigger Screw	3744	Drag Click	5628	Line Roller Collar
0787	Nut Lock Screw	3745	Oscillating Slider	5629	Line Roller Bushing
0792	Bearing Retainer Screw	3746	Oscillating Slider Retainer	5630	Line Roller
0930	Ball Bearing	3747	Slider Retainer Screw	6733	Bail Assembly
1008	Handle Lock Washer	3869	Anti-Reverse Lock Out Spring	7050	Main Shaft Assembly
1596	Bushing Washer	4051	Bail Spring	7090	Spool Assembly
1891	Bail Spring Cover Screw	4093	Anti-Reverse Cam	7091	Body Set
2257	Drag Washer "H" (blue)	4096	Drag Shaft	7092	Rotor Assembly
2280	Anti-Reverse Lock Out	4097	Pressure Screw		