



# SYMETRE 2000RH<sub>01</sub>

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0041	Drive Gear Washer	4704	Rear Cover Screw (long)	6482	Protector Screw (large)
0050	Anti-Reverse Lever Screw	4749	Bail Arm Screw	6483	Bail Hold Support Spacer
0064	Click Gear	4838	Drive Gear Bushing	6486	Roller Clutch Screw
0071	Rotor Nut	5222	Idle Gear Lock	6494	Drive Gear
0544	Drag Washer "C" (cloth)	5224	Idle Gear	6509	Bail Assembly
0560	Lever Hold Spring	5225	Oscillating Guide Retainer	6576	Bail Spring Cover
0806	Bail Hold Support Screw	5226	Anti-Reverse Lever	6577	Rotor
0912	Drag Programmer Screw	5229	Slider Retainer Screw	6673	Bail Arm
0930	Ball Bearing	5230	Oscillating Slider Retainer	6887	Roller Clutch Assembly
1008	Handle Lock Washer	5231	Oscillating Slider	6888	Worm Bushing
1356	Eared Washer "B"	5233	Drag Washer "H" (cloth)	6890	Anti-Reverse Cam
1520	Anti-Reverse Cam Spring	5236	Drag Washer "H" (white plastic)	6891	Oscillating Guide
2256	Drag Washer "C" (blue)	5237	Eared Washer "B"	6894	Oscillating Slider Bushing
2298	Spacer	5241	Hold Click Spring	6899	Drag Washer "C" (cloth)
2409	Worm Shaft Spacer	5242	Fightin' Pressure Screw Washer	6900	Drag Shaft (B)
2852	Handle Screw Lock	5243	Fightin' Pressure Screw	6901	Drag Shaft (A)
2934	Clutch Cover Screw	6042	Friction Ring	6902	Drag Washer "F" (white plastic)
3061	Side Cover Screw	6077	Click Pin	6903	Key Washer "A"
3306	Ball Bearing	6085	Line Roller	6904	Drag Coil Spring
3309	Line Roller Screw	6289	Nut Lock Screw	6905	Pressure Screw
3402	Protector Screw (small)	6290	Rotor Nut Lock Plate	6906	Lever Click Gear
3481	Bushing	6296	Click Spring	6948	Main Shaft
4150	Rear Cover Screw (short)	6297	Bail Spring Guide (A)	6950	Worm Shaft
4421	Handle Screw Cap	6307	Bail Hold Support Shaft	6971	Side Cover Assembly
4454	Handle Assembly	6329	Bearing Spacer	6972	Body
4640	Bail Spring	6330	Line Roller Bushing	6974	Fightin' Drag II Lever
4652	Lever Spring Guide (B)	6331	Line Roller Spacer	6975	Drag Programmer
4653	Lever Spring	6332	Line Roller Washer	6976	Spool Assembly (aluminum)
4654	Lever Spring Guide (A)	6333	Bail Spring Guide (B)	6977	Spool Assembly (graphite)
4656	Trip Lever Spacer	6337	Rotor Protector	6978	Rear Cover
4678	Oscillating Pawl	6338	Bail Trip Lever	7279	Pinion Gear