


SHIMANO

STRADIC



STR-5000FB



(1SG085014G)

Part No.	Description	Part No.	Description	Part No.	Description
RD 0041	Washer	RD 7926	Screw	RD10430	Pinion Gear
RD 0071	Rotor Nut	RD 7927	Washer	RD10431	Anti-Reverse Cam
RD 0787	Screw	RD 7944	Bail Trip Strike	RD10432	Anti-Reverse Lever Cover
RD 1008	Handle Lock Washer	RD 7945	Nut	RD10433	Worm Bushing (front)
RD 1520	Anti-Reverse Cam Spring	RD 7988	Drive Gear	RD10434	Idle Gear
RD 2293	Drive Gear Bushing	RD 8147	Friction Ring	RD10435	Worm Shaft
RD 2298	Spacer	RD 8579	Bail Spring Cover	RD10438	Oscillating Pawl Cover
RD 2409	Spacer	RD 9501	Click Spring	RD10439	Oscillating Slider
RD 2852	Handle Screw Lock	RD 9502	Bail Trip Lever	RD10440	Rear Protector
RD 3177	Key Washer	RD 9872	Screw	RD10441	Ball Bearing
RD 3503	Spool Washer	RD 9975	Oscillating Slider Bushing	RD10442	Worm Shaft Retainer
RD 3571	Screw	RD10306	Drag Click Collar	RD10443	Oscillating Guide
RD 4749	Screw	RD10320	Ball Bearing	RD10444	Screw
RD 4777	Screw	RD10345	Drag Washer	RD10445	Screw
RD 4829	Screw	RD10352	Spool Support	RD10495	Handle Screw Cap
RD 5690	Screw	RD10385	Key Washer	RD10523	Bail Assembly
RD 6010	Screw	RD10397	Ball Bearing	RD10525	Handle Assembly
RD 6061	Oscillating Pawl	RD10406	Anti-Reverse Lever	RD10576	Screw
RD 6130	Roller Clutch Assembly	RD10415	Drag Washers Retainer	RD10585	Click Spring
RD 6265	Screw	RD10416	Eared Washer	RD10601	Drag Knob
RD 6482	Screw	RD10417	Drag Click	RD10602	Spool Assembly
RD 6524	Worm Bushing (rear)	RD10419	Main Shaft	RD10603	Bail Arm
RD 7787	Bail Spring Guide A	RD10420	Bearing Spacer	RD10604	Rotor
RD 7788	Spring Guide A Support	RD10421	Line Roller Collar	RD10605	Side Cover
RD 7875	Oil Cap	RD10422	Line Roller	RD10606	Body
RD 7920	Click Pin	RD10423	Line Roller Bushing	RD10746	Oscillating Guide B
RD 7921	Bail Spring	RD10424	Ball Bearing		
RD 7922	Bail Spring Seat	RD10427	Bail Hold Support Guard		
RD 7924	Bail Trip Cover	RD10429	Line Roller Support	RD10607	Spare Spool Assembly

(181030)