

ALIVIO

This diagram illustrates the assembly of a mechanical component, likely a bearing housing or a similar part. It features a large central housing with various internal and external components. The parts are numbered as follows:

- 4367, 12008, 4749, 3492, 5947, 11756, 11724, 10793, 10752, 11159, 521, 12006, 12009, 5947, 11758, 3492, 11718, 787, 12010, 4749, 12004, 12005, 6685, 11723, 12007, 5629, 5628, 11717, 3503, 3503, 10723, 10721, 1868, 3273, 10695, 9442, 5947, 10696, 5455, 10719, 5690, 10694, 3204, 5447, 5040, 5040, 5040, 5040, 10722, 3492, 10702, 10701, 3665, 3665, 4362, 4362, 642, 4362, 10724, 4004, 10696, 743, 743, 4004, 10720, 10722, 3492, 10702, 10701, 3665, 3665, 4362, 4362, 642, 4362, 10724.

The diagram also includes a small inset showing a detail of a bearing assembly with a "MARKING PIN" and a "MARKING" label. The watermark "RoulementCasting.com" is prominently displayed across the bottom of the image.