


SHIMANO

CORE S A-RB

COR-101MG



(51RH590101U)

Part No.	Description	Part No.	Description	Part No.	Description
BNT0015	Drag Spring Washer	BNT3148	Screw	BNT3872	Star Drag
BNT0032	Bearing Retainer	BNT3169	Pawl Cap	BNT3874	Drive Gear
BNT0060	Spacer	BNT3429	Quick-Fire II Clutch Bar	BNT3875	Drive Shaft
BNT0664	Spacer B	BNT3481	Drag Washer	BNT3876	Worm Shaft
BNT0686	E Lock	BNT3540	Screw	BNT3877	Worm Bushing A
BNT0817	Screw	BNT3548	Drag Washer	BNT3878	Pinion Gear
BNT1419	Yoke Spring	BNT3577	Clutch Pawl Spring	BNT3879	Clutch Cam
BNT1672	E Lock	BNT3621	Ball Bearing	BNT3880	Clutch Pawl
BNT1696	Cast Control Spacer	BNT3630	Roller Clutch Inner Tube	BNT3882	Clutch Guard
BNT1715	Brake Collar (red)	BNT3664	Star Drag Nut	BNT3883	Clutch Bar Guide B
BNT1866	Spacer	BNT3811	Cast Control Cap	BNT3884	Side Plate Cam Lever
BNT2120	Click Plate Retainer	BNT3812	Ball Bearing	BNT3885	Level Wind Protector
BNT2122	Click Pin	BNT3813	Damper Spring	BNT3887	Side Frame Plate
BNT2123	Click Spring	BNT3814	Key Washer	BNT3888	Right Side Plate
BNT2127	Star Drag Spacer	BNT3816	Anti-Reverse Ratchet	BNT3902	Handle Retainer
BNT2144	Washer	BNT3818	Drive Shaft Retainer	BNT3905	One-Piece Frame
BNT2150	Line Guide Pawl	BNT3819	Ball Bearing	BNT4105	Left Side Plate
BNT2154	Idle Gear	BNT3820	Line Guide	BNT4316	Screw
BNT2200	Handle Nut	BNT3821	Level Wind Guide	BNT4317	Screw
BNT2201	Star Drag Spring	BNT3825	Screw	BNT4318	Screw
BNT2212	Yoke	BNT3826	Clutch Cam Retainer	BNT4858	Clutch Plate
BNT2224	Spool Tension Spacer	BNT3831	Screw	BNT5860	Star Drag Click Plate
BNT2400	Idle Gear	BNT3834	O Ring		
BNT2429	O Ring	BNT3836	Line Guard Retainer		
BNT2717	E Lock	BNT3837	Screw		
BNT3036	Level Wind Guard	BNT3840	Spool Assembly	BNT1713	Brake Collar (green) (accessory)
BNT3041	Clutch Plate Shaft Support	BNT3841	Brake Case	BNT3174	Reel Seat Spacer (accessory)
BNT3045	Worm Bushing B	BNT3871	Handle Assembly	BNT3237	Wrench (accessory)