


SHIMANO

STRADIC

A-RB

ST-4000FI



| Part No. | Description | Part No. | Description | Part No. | Description |
|----------|-------------------------|----------|----------------------------|----------|-----------------------------------|
| RD 0071 | Rotor Nut | RD 8916 | Click Spring | RD10752 | Spring Guide A Support |
| RD 0786 | Screw | RD 9841 | Click Pin | RD10753 | Bail Spring |
| RD 0787 | Screw | RD 9872 | Screw | RD10756 | Bail Spring Seat |
| RD 1520 | Anti-Reverse Cam Spring | RD 9975 | Oscillating Slider Bushing | RD11077 | Drag Washers Retainer |
| RD 2298 | Spacer | RD10000 | Line Roller | RD11146 | Washer |
| RD 2309 | Screw | RD10184 | Line Roller Bushing | RD11425 | Handle Knob I.D. Plate |
| RD 2409 | Spacer | RD10318 | Line Roller Support | RD11429 | Pinion Gear |
| RD 3177 | Key Washer | RD10340 | Screw | RD11455 | Drag Knob |
| RD 3179 | Eared Washer | RD10341 | Screw | RD11465 | Handle Knob Shaft Collar |
| RD 3402 | Screw | RD10345 | Drag Washer | RD11467 | Spool Assembly |
| RD 3481 | Bushing | RD10354 | Bearing Spacer | RD11468 | Bail Arm |
| RD 3492 | Screw | RD10364 | Worm Bushing (front) | RD11469 | Rotor |
| RD 3503 | Spool Washer | RD10367 | Anti-Reverse Cam | RD11470 | Bail Assembly |
| RD 4150 | Screw | RD10370 | Anti-Reverse Lever Cover | RD11471 | Bail Trip Strike |
| RD 4675 | Screw | RD10374 | Oscillating Pawl Cover | RD11472 | Side Cover |
| RD 4812 | Screw | RD10375 | Oscillating Slider | RD11473 | Handle Shank Assembly |
| RD 4829 | Screw | RD10381 | Handle Screw Cap | RD11474 | Handle Assembly |
| RD 5947 | Screw | RD10385 | Key Washer | RD11475 | Rear Protector |
| RD 6010 | Screw | RD10386 | Drag Click | RD11476 | Body |
| RD 6493 | Worm Bushing (rear) | RD10388 | Spool Support | RD12078 | Screw |
| RD 6684 | Line Roller Spacer | RD10389 | Main Shaft | RD13014 | Click Spring |
| RD 7463 | Line Roller Washer | RD10390 | Bail Trip Lever | RD13015 | Friction Ring |
| RD 7469 | Screw | RD10391 | Bail Trip Cover | RD13241 | Ball Bearing |
| RD 7787 | Bail Spring Guide A | RD10393 | Bail Spring Cover | RD13269 | Ball Bearing |
| RD 7857 | Oscillating Pawl | RD10395 | Bail Hold Support Guard | RD13274 | Ball Bearing |
| RD 7875 | Oil Cap | RD10399 | Friction Ring Collar | RD13374 | Ball Bearing |
| RD 7927 | Washer | RD10402 | Idle Gear | RD13643 | Drive Gear |
| RD 7945 | Nut | RD10404 | Screw | | |
| RD 8170 | Handle Knob | RD10406 | Anti-Reverse Lever | RD 3571 | Screw (before change) |
| RD 8171 | Washer | RD10411 | Worm Shaft Retainer | RD10306 | Drag Click Collar (before change) |
| RD 8172 | Handle Knob Nut | RD10412 | Oscillating Guide | RD10400 | Friction Spring (before change) |
| RD 8850 | Roller Clutch Assembly | RD10563 | Worm Shaft | RD10401 | Friction Ring (before change) |