


SHIMANO

STRADIC 

ST-6000FI



(1SE456009U)

Part No.	Description	Part No.	Description	Part No.	Description
RD 0521	Rotor Nut	RD 8654	Drag Washers Retainer	RD10617	Spool Washer
RD 0647	Screw	RD 8999	Click Pin	RD10752	Spring Guide A Support
RD 0787	Screw	RD 9444	Screw	RD10790	Bail Spring
RD 2298	Spacer	RD10420	Bearing Spacer	RD10796	Bail Spring Seat
RD 2409	Spacer	RD10421	Line Roller Collar	RD11156	Key Washer
RD 2934	Screw	RD10422	Line Roller	RD11159	Bail Spring Guide A
RD 3492	Screw	RD10423	Line Roller Bushing	RD11823	Drag Click Collar
RD 3561	Screw	RD10429	Line Roller Support	RD11825	Main Shaft
RD 4675	Screw	RD10444	Screw	RD11827	Pinion Gear
RD 4749	Screw	RD10449	Drag Click	RD11828	Drive Gear
RD 5040	Screw	RD10450	Click Spring	RD11834	Rear Protector
RD 5947	Screw	RD10455	Spool Support	RD11848	Spool Assembly
RD 6192	Washer	RD10457	Bail Trip Lever	RD11849	Bail Arm
RD 6204	Oscillating Pawl Cover	RD10459	Bail Spring Cover	RD11850	Rotor
RD 6206	Oscillating Pawl	RD10461	Rotor Side Cover	RD11851	Bail Assembly
RD 6227	Washer	RD10465	Oscillating Slider Bushing	RD11852	Side Cover
RD 6395	Roller Clutch Assembly	RD10466	Bail Trip Strike	RD11853	Handle Assembly
RD 6524	Worm Bushing (rear)	RD10468	Anti-Reverse Cam	RD11854	Body
RD 7875	Oil Cap	RD10469	Worm Bushing (front)	RD12018	Anti-Reverse Lever Cover
RD 7919	Click Spring	RD10470	Idle Gear	RD13185	Ball Bearing
RD 7926	Screw	RD10471	Worm Shaft	RD13188	Ball Bearing
RD 7945	Nut	RD10477	Oscillating Slider	RD13189	Ball Bearing
RD 8257	Screw	RD10479	Worm Shaft Retainer	RD13274	Ball Bearing
RD 8594	Eared Washer	RD10480	Oscillating Guide	RD13646	Drag Knob
RD 8600	Bail Trip Cover	RD10482	Screw	RD13893	Drag Washer
RD 8608	Friction Ring	RD10483	Handle Screw Cap	RD13894	Drag Washer

(220517)