


# SHIMANO

## CAENAN

CAE-100



(51RH600100U)

Part No.	Description	Part No.	Description	Part No.	Description
BNT0015	Drag Spring Washer	BNT3219	Idle Gear	BNT4126	Right Side Plate
BNT0042	Line Guide Pawl	BNT3474	Roller Clutch Inner Tube	BNT4129	Drive Gear
BNT0194	Ball Bearing	BNT3495	Yoke	BNT4130	Drag Washer
BNT0425	E Lock	BNT3508	Screw	BNT4131	Anti-Reverse Ratchet
BNT0609	Screw	BNT3595	Pawl Cap	BNT4132	Drive Shaft
BNT0623	Screw	BNT3770	Key Washer	BNT4133	Idle Gear
BNT0664	Spacer B	BNT3771	Drag Washer	BNT4134	Worm Shaft
BNT0817	Screw	BNT3776	Ball Bearing	BNT4135	Level Wind Guard
BNT0830	Spacer	BNT3843	Brake Collar (orange)	BNT4136	Level Wind Protector
BNT1133	Yoke Spring	BNT3934	Brake Case Spacer	BNT4137	Drive Shaft Cover
BNT1289	Star Drag Spacer	BNT3935	Brake Spring Retainer	BNT4138	Pinion Gear
BNT1465	Clutch Pawl Spring	BNT3936	Click Spring	BNT4139	Clutch Pawl
BNT1476	Washer	BNT3937	Click Pin	BNT4140	Clutch Plate
BNT1671	Washer	BNT4003	Line Guide	BNT4141	One-Piece Frame
BNT1672	E Lock	BNT4113	Handle Retainer	BNT4142	Quick-Fire II Clutch Bar
BNT1696	Cast Control Spacer	BNT4114	Handle Knob Seal	BNT4143	Stabilizer Bar
BNT1949	Screw	BNT4115	O Ring	BNT4145	CR Lock
BNT2122	Click Pin	BNT4116	Screw	BNT4146	Brake Case
BNT2123	Click Spring	BNT4117	Handle Knob Bushing	BNT4147	Damper Spring
BNT2165	Clutch Cam Retainer	BNT4118	Washer	BNT4148	Left Side Plate
BNT2179	Screw	BNT4119	Handle Knob	BNT4149	Turnkey Dial
BNT2221	Handle Nut	BNT4120	Ball Bearing	BNT4280	Clutch Cam
BNT2224	Spool Tension Spacer	BNT4121	Handle Shank Assembly	BNT4291	Cast Control Cap
BNT2396	Roller Clutch Bearing	BNT4122	Handle Assembly	BNT4587	Washer
BNT2717	E Lock	BNT4123	Star Drag	BNT4930	Spool Assembly
BNT2921	Screw	BNT4124	Star Drag Spring	BNT5306	Spool Tension Spring
BNT3208	Star Drag Click Plate	BNT4125	Star Drag Nut		