


SHIMANO

POWER AERO SA-RB

PA-14000XSB



Please note that the number of adjusting washers may not be the same as shown in the exploded views.
(Adjustment will vary with each individual product.)

(51SA61U140X)

Part No.	Description	Part No.	Description	Part No.	Description
RD 0540	Screw	RD13185	Ball Bearing	RD18575	Main Shaft
RD 0642	Screw	RD13188	Ball Bearing	RD18576	Line Roller Support Collar
RD 0786	Screw	RD14173	Ball Bearing	RD18577	Line Roller Set(With Bearing)
RD 0787	Screw	RD14279	Washer	RD18578	Bearing Spacer
RD 1520	Anti-Reverse Cam Spring	RD14944	Spool Support B	RD18579	Bail Arm
RD 2110	Screw	RD14961	Washer	RD18580	Bail Spring Cover
RD 2298	Spacer	RD15150	E Lock	RD18581	Rotor Assembly
RD 3232	Rotor Nut	RD15152	Bail Spring Guide A	RD18582	Bail Hold Support Guard
RD 4150	Screw	RD15153	Bail Spring Guide A Support	RD18583	Line Roller Support
RD 5040	Screw	RD15155	Bail Spring Guide B	RD18584	Bail Assembly
RD 5042	Anti-Reverse Cam Ring	RD15161	Lever Spring	RD18586	Idle Gear B Shaft
RD 5676	Spool Washer	RD15163	Washer	RD18587	Idle Gear C Shaft
RD 5705	Roller Clutch Ring	RD15175	Oscillating Pawl Cover	RD18588	Anti-Reverse Lever
RD 5706	Roller Clutch Assembly	RD15177	Idle Gear B	RD18589	Idle Gear
RD 5707	Bearing Washer	RD15180	Worm Shaft Retainer	RD18590	Drive Gear
RD 5725	Oscillating Pawl	RD15200	Screw	RD18591	Side Cover Assembly
RD 5947	Screw	RD15331	Bail Spring	RD18592	Handle Shaft Cover
RD 6606	Screw	RD15652	Screw	RD18593	Handle Shank Assembly
RD 7583	E Lock	RD16063	Bail Trip Lever	RD18594	Handle Knob
RD 7859	Screw	RD16825	Washer	RD18595	Handle Assembly
RD 7875	Oil Cap	RD17610	Line Clip	RD18596	Oscillating Slider Bushing
RD 7926	Screw	RD17611	Line Clip Holder	RD18597	Oscillating Slider
RD 8322	Washer	RD17612	Line Clip Spring	RD18598	Rear Protector
RD 8339	Handle Shaft Seal	RD17636	Idle Gear C	RD18599	Worm Shaft
RD 8480	Anti-Reverse Cam	RD17751	Ball Bearing	RD18600	Oscillating Guide B
RD 9162	Spool Washer	RD17925	Drag Washer	RD18601	Oscillating Guide
RD 9191	Screw	RD17926	Drag Click	RD18602	Idle Gear B Collar
RD11018	Ball Bearing	RD18321	Washer	RD18603	Body
RD11111	Ball Bearing	RD18411	Handle Knob Seal	RD18648	Pinion Gear
RD11924	Seal Plate	RD18510	Handle Screw Cap Holder	RD18678	Drag Click Spring
RD11926	Eared Washer	RD18511	Handle Screw Cap		
RD11927	Key Washer	RD18569	Drag Knob Assembly		
RD11968	O Ring	RD18570	Screw		
RD11971	Worm Bushing (Front)	RD18571	Spool Assembly	RD18604	Spare Spool Assembly (accessory)
RD12469	O Ring	RD18572	Spool Support A	RD16070	Spool Economizer A (10000) (accessory)
RD12737	Screw	RD18573	Line Safety Guard Assembly	RD16071	Spool Economizer B (6000) (accessory)
RD12973	Key Washer	RD18574	Rotor Brim	RD16072	Spool Economizer C (3500) (accessory)