


SHIMANO

STELLA  A-RB

STL-2500S



RoulementCasting.com

* (18735) Please send the equipment out to after-sales service for replacement of the roller clutch assembly.

Please note that the number of adjusting washers may not be the same as shown in the exploded views.

(51SF14E027X) (Adjustment will vary with each individual product.)

| Part No. | Description | Part No. | Description | Part No. | Description |
|----------|------------------------|----------|--|----------|------------------------------|
| RD 2110 | Screw | RD16473 | Oscillating Pawl | RD18736 | O Ring |
| RD 2409 | Spacer | RD16478 | Screw | RD18737 | Roller Clutch Inner |
| RD 6008 | Set Screw | RD16479 | Worm Shaft Retainer | RD18738 | Bearing Retainer |
| RD 7979 | Drag Washers Retainer | RD16480 | O Ring | RD18739 | Washer |
| RD 8013 | Screw | RD16665 | Line Roller Support | RD18740 | Pinion Gear |
| RD 8165 | Washer | RD17467 | Bail Spring | RD18741 | Washer |
| RD 8216 | Washer | RD17468 | Bail Spring Guide B | RD18742 | Oscillating Guide A |
| RD 8759 | Click Pin | RD17479 | Idle Gear B Shaft | RD18744 | Idle Gear |
| RD 9833 | Ratchet Spring | RD17801 | Key Washer | RD18745 | Drive Gear |
| RD 9847 | Screw | RD18160 | Bearing Spacer | RD18746 | Bail Trip Strike |
| RD 9849 | Screw | RD18207 | Drag Click Ratchet | RD18747 | Flange Water Proof |
| RD 9856 | Washer | RD18448 | Line Roller Set (With Bearing) | RD18748 | Side Cover Assembly |
| RD 9903 | O Ring | RD18709 | Drag Knob Assembly | RD18749 | Handle Shaft Cover B |
| RD 9908 | Drag Washer | RD18711 | Drag Click | RD18750 | Handle Shank Assembly |
| RD 9912 | Bearing Retainer | RD18713 | Spool Washer | RD18751 | Handle Knob Pipe |
| RD 9931 | Click Spring | RD18714 | Bearing Bushing | RD18752 | Handle Knob Assembly |
| RD 9968 | O Ring | RD18715 | Main Shaft Spacer Assembly(With Bearing) | RD18753 | Handle Knob Seal |
| RD10906 | Ball Bearing | RD18716 | Rotor Nut | RD18754 | Handle Assembly |
| RD11018 | Ball Bearing | RD18717 | Screw | RD18755 | Oscillating Slider Bushing |
| RD11568 | Screw | RD18718 | Rotor Brim | RD18756 | Main Shaft Assembly |
| RD11578 | Ball Bearing | RD18719 | Bail Arm | RD18757 | Rear Protector |
| RD11713 | Screw | RD18720 | Screw | RD18758 | Washer |
| RD13241 | Ball Bearing | RD18721 | Bail Spring Cover | RD18759 | Worm Shaft |
| RD13269 | Ball Bearing | RD18722 | Rotor Assembly | RD18760 | Oscillating Guide B |
| RD13274 | Ball Bearing | RD18723 | Bail Trip Lever | RD18761 | Idle Gear (Small) |
| RD13381 | Ball Bearing | RD18724 | Spring Guide A Support | RD18762 | Washer |
| RD14279 | Washer | RD18725 | Bail Spring Guide A | RD18763 | Idle Gear (Large) |
| RD14780 | Screw | RD18726 | Bail Spring Guide A Bush | RD18764 | Handle Screw Cap |
| RD14867 | Spool Support | RD18727 | Bail Assembly | RD19008 | Ball Bearing |
| RD15489 | Drag Click Spring | RD18728 | Bail Trip Cam Bushing | RD19031 | Washer |
| RD15718 | Screw | RD18729 | Screw | RD19196 | Spool Assembly |
| RD15991 | Rotor Nut Lock Plate | RD18730 | Bail Hold Support Guard | RD19197 | Body Assembly |
| RD16426 | Screw | RD18731 | Rotor Side Cover | RD19224 | Washer |
| RD16427 | Bearing Water Proof | RD18732 | Rotor Ring | | |
| RD16451 | Screw | RD18733 | Friction Ring | | |
| RD16465 | Handle Shaft Seal | RD18734 | Screw | | |
| RD16470 | Oscillating Pawl Cover | RD18735 | Roller Clutch Assembly | RD 9811 | Reel Seat Spacer (accessory) |