


# CALCUTTA



100 <sup>97</sup>

*RoulementCasting.com*

| BNT No. | PARTS NAMES              | BNT No. | PARTS NAMES                     | BNT No. | PARTS NAMES               |
|---------|--------------------------|---------|---------------------------------|---------|---------------------------|
| 0009    | Cast Control Spacer      | 1227    | Clutch Pawl Spring Retainer     | 1435    | Clutch Pawl Spacer        |
| 0011    | Right Side Plate Screw   | 1230    | Drive Shaft Spacer              | 1436    | Clutch Pawl               |
| 0015    | Drag Spring Washer       | 1234    | Level Wind Guide                | 1437    | Clutch Pawl Spring        |
| 0032    | Bearing Retainer         | 1237    | Worm Bushing (A) Retainer Screw | 1438    | Drive Shaft Bushing       |
| 0036    | Left Side Plate Screw    | 1239    | Pawl Cap                        | 1439    | Spool Assembly            |
| 0042    | Line Guide Pawl          | 1240    | Line Guide                      | 1440    | Worm Bushing (A) Retainer |
| 0133    | Worm Shaft Retainer      | 1241    | Level Wind Guard                | 1441    | One-Piece Frame           |
| 0188    | "O" Ring                 | 1243    | Worm Bushing (B)                | 1442    | Clutch Bar Guide (B)      |
| 0192    | Left Side Plate Screw    | 1252    | Right Side Plate Bolt Washer    | 1443    | Quick-Fire II Clutch Bar  |
| 0194    | Ball Bearing             | 1289    | Star Drag Spacer                | 1444    | Left Side Plate           |
| 0425    | "E" Lock                 | 1327    | Idle Gear                       | 1447    | Drive Shaft               |
| 0586    | Bolt Retainer            | 1337    | Clutch Bar Support Spacer       | 1448    | Anti-Reverse Ratchet      |
| 0609    | Clutch Cam Screw         | 1338    | Clutch Bar Guide (A)            | 1476    | Worm Shaft Spacer         |
| 0664    | Spacer (B)               | 1420    | Star Drag                       | 1587    | Pinion Gear               |
| 0686    | Idle Gear (B) Retainer   | 1421    | Right Side Plate                | 1692    | Handle Nut Plate          |
| 0795    | Handle Nut Plate Screw   | 1423    | Key Washer                      | 1699    | Worm Bushing (A)          |
| 0797    | Handle Nut               | 1424    | Drag Washer (C)                 | 1712    | Handle Assembly           |
| 0799    | Friction Washer          | 1425    | Drive Gear                      | 1714    | Worm Shaft                |
| 0830    | Spacer (optional)        | 1426    | Drive Shaft                     | 1715    | Brake Collar (red)        |
| 1133    | Yoke Spring              | 1428    | Yoke                            | 1910    | Cast Control Cap          |
| 1201    | Retractor Spring Collar  | 1429    | Clutch Cam Retainer             | 1916    | Clutch Bar Support        |
| 1206    | Roller Clutch Inner Tube | 1430    | Clutch Cam                      |         |                           |
| 1207    | Roller Clutch Bearing    | 1431    | Retractor Spring                |         |                           |
| 1208    | Right Side Plate Bolt    | 1432    | Clutch Plate                    |         |                           |
| 1214    | Drag Washer (A)          | 1433    | Idle Gear (B)                   |         |                           |
| 1218    | Idle Gear (A) Spacer     | 1434    | Set Plate                       | 1713    | Brake Collar (green)      |