




4000

97

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0041	Drive Gear Washer	2016	Drag Washer "H" (cloth)	4274	Drag Shaft
0050	Anti-Reverse Lever Screw	2257	Drag Washer "H" (blue)	4275	Drag Knob
0071	Rotor Nut	2293	Drive Gear Bushing	4277	Main Shaft
0080	Line Roller	2346	Drag Washer "C" (cloth)	4306	Lock Out Spring Holder
0111	Drag Coil Spring	2433	Pressure Screw	4307	Anti-Reverse Lock Out
0452	Drag Spring Washer	2541	Anti-Reverse Pawl Screw	4308	Anti-Reverse Pawl
0540	Multi-Purpose Screw	2852	Handle Screw Lock	4309	Anti-Reverse Cam
0579	Eared Washer "B"	3681	Bail Spring Guide (A)	4310	Drag Click
0584	Hold Click Spring	3682	Bail Spring	4314	Spool Assembly
0779	Multi-Purpose Screw	3695	Oscillating Gear	4317	Bail Spring Cover
0787	Nut Lock Screw	3747	Slider Retainer Screw	4318	Bail Trip Lever
0792	Bushing Retainer Screw	3766	Oscillating Slider	4362	Side Cover Screw
0815	Line Roller Washer	3767	Oscillating Slider Retainer	4367	Line Roller Screw
0826	Key Washer "A"	3794	Drag Knob Screw	4379	Anti-Reverse Lever
1008	Handle Lock Washer	3869	Anti-Reverse Lock Out Spring	4392	Bail Arm
1030	Handle Assembly	3873	Anti-Reverse Pawl Spring	5167	Bushing Spacer
1442	Handle Screw Cap	4259	Spool Washer	5173	Pinion Gear
1511	Lever Spring	4260	Spool Support	5176	Rotor
1515	Bushing	4264	Bail Spring Guide (B)	5177	Bail Assembly
1520	Anti-Reverse Cam Spring	4267	Bail Trip Lever Washer	5178	Side Cover
1596	Bushing Washer	4272	Drive Gear	5179	Body

(080715)