



STRADIC 1000GTM

| RD No. | PARTS NAMES | RD No. | PARTS NAMES | RD No. | PARTS NAMES |
|--------|---------------------------------|--------|----------------------------|--------|----------------------------------|
| 0041 | Drive Gear Washer | 4643 | Bail Arm Bushing | 5221 | Worm Bushing |
| 0050 | Anti-Reverse Lever Screw | 4649 | Spacer | 5222 | Idle Gear Lock |
| 0064 | Click Gear | 4650 | Bail Hold Support Shaft | 5223 | Worm Shaft |
| 0544 | Drag Washer "C" (cloth) | 4652 | Lever Spring Guide (B) | 5224 | Idle Gear |
| 0560 | Lever Hold Spring | 4653 | Lever Spring | 5225 | Oscillating Guide Retainer |
| 0912 | Drag Programmer Screw | 4654 | Lever Spring Guide (A) | 5226 | Anti-Reverse Lever |
| 0930 | Ball Bearing | 4655 | Bail Trip Lever | 5227 | Side Cover Flange |
| 1008 | Handle Lock Washer | 4656 | Trip Lever Spacer | 5228 | Side Cover |
| 1356 | Eared Washer "B" | 4658 | Clutch Cover Screw | 5229 | Slider Retainer Screw |
| 1520 | Anti-Reverse Cam Spring | 4661 | Anti-Reverse Cam Ring | 5230 | Oscillating Slider Retainer |
| 1891 | Multi-Purpose Screw | 4667 | Drive Gear | 5231 | Oscillating Slider |
| 2254 | Ball Bearing | 4677 | Oscillating Slider Bushing | 5232 | Rear Cover |
| 2256 | Drag Washer "C" (blue) | 4678 | Oscillating Pawl | 5233 | Drag Washer "H" (cloth) |
| 2298 | Spacer | 4792 | Bail Arm | 5234 | Drag Shaft (A) |
| 2315 | Lever Click Gear | 4793 | Bail Spring Cover | 5235 | Drag Shaft (B) |
| 2404 | "E" Lock | 4794 | Bail Hold Support Guard | 5236 | Drag Washer "H" (white plastics) |
| 2409 | Worm Shaft Spacer | 4795 | Bail Hold Support Spacer | 5237 | Eared Washer "B" |
| 2715 | Rotor Nut | 4798 | Roller Clutch Screw | 5238 | Drag Coil Spring |
| 2852 | Handle Screw Lock | 4799 | Pinion Gear | 5239 | Pressure Screw |
| 3061 | Side Cover Screw | 4812 | Rear Cover Screw (small) | 5240 | "O" Ring |
| 3309 | Line Roller Screw | 4999 | Line Roller Bushing | 5241 | Hold Click Spring |
| 3402 | Bail Spring Cover Screw (small) | 5000 | Line Roller Collar | 5242 | Fightin' Pressure Screw Washer |
| 3481 | Bushing | 5001 | Line Roller Washer | 5243 | Fightin' Pressure Screw |
| 4421 | Handle Screw Cap | 5215 | Spool Assembly | 5244 | Fightin' Drag II Lever |
| 4469 | Double Paddle Handle Assembly | 5216 | Main Shaft | 5245 | Drag Programmer |
| 4631 | Spacer | 5217 | Rotor | 5246 | Body |
| 4639 | Bail Spring Guide (A) | 5218 | Roller Clutch Assembly | 5350 | Line Roller |
| 4640 | Bail Spring | 5219 | Anti-Reverse Cam | 5355 | Bail Assembly |
| 4641 | Bail Spring Guide (B) | 5220 | Oscillating Guide | 5541 | Bail Arm Screw |