



FX1000F 99

| RD No. | PARTS NAMES | RD No. | PARTS NAMES | RD No. | PARTS NAMES |
|--------|--------------------------|--------|--------------------------|--------|------------------------------|
| 0041 | Drive Gear Washer | 3455 | Spool Washer | 4367 | Line Roller Screw |
| 0050 | Anti-Reverse Lever Screw | 3471 | Anti-Reverse Cam Spring | 4388 | Bail Arm |
| 0080 | Line Roller | 3645 | Drag Knob | 5166 | Bail Assembly |
| 0642 | Side Cover Screw | 3663 | Oscillating Gear | 5580 | Spool Assembly |
| 0779 | Multi-Purpose Screw | 3665 | Slider Retainer Screw | 5581 | Main Shaft |
| 0815 | Line Roller Washer | 3848 | Bail Spring Guide (A) | 5582 | Rotor Assembly |
| 1008 | Handle Lock Washer | 3856 | Anti-Reverse Pawl | 5583 | Anti-Reverse Lock Out Spring |
| 1025 | Handle Assembly | 3857 | Anti-Reverse Pawl Spring | 5584 | Anti-Reverse Lock Out |
| 1427 | Spool Support | 3858 | Anti-Reverse Cam | 5585 | Rotor Lock |
| 1442 | Handle Screw Cap | 4051 | Bail Spring | 5586 | Pinion Bushing (back) |
| 1514 | Bushing Washer | 4295 | Bail Spring Guide (B) | 5587 | Drive Gear |
| 1891 | Multi-Purpose Screw | 4296 | Bail Spring Cover | 5588 | Side Cover |
| 2283 | Anti-Reverse Pawl Screw | 4297 | Bail Trip Lever | 5589 | Body |
| 2293 | Drive Gear Bushing | 4298 | Counterbalance Cover | 5791 | Bushing |
| 2852 | Handle Screw Lock | 4351 | Anti-Reverse Lever | 5793 | Oscillating Slider |