



FX4000F 99

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0041	Drive Gear Washer	2852	Handle Screw Lock	4367	Line Roller Screw
0050	Anti-Reverse Lever Screw	3503	Spool Washer	4392	Bail Arm
0080	Line Roller	3665	Slider Retainer Screw	5177	Bail Assembly
0540	Multi-Purpose Screw	3676	Drag Knob	5598	Spool Assembly
0642	Side Cover Screw (small)	3677	Main Shaft	5599	Rotor Assembly
0779	Multi-Purpose Screw	3681	Bail Spring Guide (A)	5600	Anti-Reverse Lock Out Spring
0815	Line Roller Washer	3682	Bail Spring	5601	Anti-Reverse Lock Out
1008	Handle Lock Washer	3695	Oscillating Gear	5602	Anti-Reverse Pawl
1030	Handle Assembly	3874	Anti-Reverse Cam	5603	Rotor Lock
1442	Handle Screw Cap	4264	Bail Spring Guide (B)	5604	Pinion Bushing (back)
1511	Lever Spring	4267	Bail Trip Lever Washer	5605	Drive Gear
1520	Anti-Reverse Cam Spring	4317	Bail Spring Cover	5606	Side Cover
1957	Bushing Washer	4318	Bail Trip Lever	5607	Body
2293	Drive Gear Bushing	4351	Anti-Reverse Lever	5646	Anti-Reverse Pawl Spring
2516	Spool Support	4360	Side Cover Flange	5792	Bushing
2541	Anti-Reverse Pawl Screw	4362	Side Cover Screw (large)	5794	Oscillating Slider