



4000 99

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0026	Ball Bearing	2541	Anti-Reverse Pawl Screw	4308	Anti-Reverse Pawl
0041	Drive Gear Washer	2852	Handle Screw Lock	4309	Anti-Reverse Cam
0050	Anti-Reverse Lever Screw	3359	Line Roller Washer	4362	Side Cover Screw
0071	Rotor Nut	3402	Cover Screw	4367	Line Roller Screw
0111	Drag Coil Spring	3681	Bail Spring Guide (A)	4421	Handle Screw Cap
0452	Drag Spring Washer	3682	Bail Spring	4614	Bail Arm
0540	Multi-Purpose Screw	3683	Bail Spring Guide (B)	4906	Anti-Reverse Lever
0579	Eared Washer "B"	3695	Oscillating Gear	4926	Drag Knob
0584	Hold Click Spring	3747	Slider Retainer Screw	5548	Handle Assembly
0779	Multi-Purpose Screw	3765	Drag Click	5625	Line Roller Spacer
0787	Nut Lock Screw	3766	Oscillating Slider	5628	Line Roller Collar
0792	Bearing Retainer Screw	3767	Oscillating Slider Retainer	5629	Line Roller Bushing
0826	Key Washer "A"	3794	Drag Knob Screw	5635	Bail Spring Cover
1008	Handle Lock Washer	3869	Anti-Reverse Lock Out Spring	5640	Spool Assembly
1511	Lever Spring	3873	Anti-Reverse Pawl Spring	5641	Bail Assembly
1520	Anti-Reverse Cam Spring	3886	Bail Trip Lever	5642	Line Roller
1596	Bushing Washer	4274	Drag Shaft	5643	Rotor
2016	Drag Washer "H" (cloth)	4281	Pinion Gear	5644	Counterbalance Cover
2257	Drag Washer "H" (blue)	4282	Drive Gear	5645	Body Set
2293	Drive Gear Bushing	4290	Main Shaft	6812	Pair of Spool Economizers
2346	Drag Washer "C" (cloth)	4306	Lock Out Spring Holder		
2433	Pressure Screw	4307	Anti-Reverse Lock Out		