


SHIMANO®

SUPER AERO

SUA-1000F



Part No.	Description	Part No.	Description	Part No.	Description
RD0041	Drive Gear Washer	RD3467	Bushing Washer	RD5063	Pinion Gear
RD0071	Rotor Nut	RD3468	Bearing Retainer Screw	RD5064	Idle Gear
RD0642	Side Cover Screw	RD3469	Bearing Retainer	RD5065	Worm Shaft
RD0787	Nut Lock Screw	RD3471	Anti-Reverse Cam Spring	RD5066	Drive Gear
RD1008	Handle Lock Washer	RD3472	Anti-Reverse Cam	RD5106	Oscillating Pawl
RD1509	Bail Spring	RD3473	Anti-Reverse Pawl Screw	RD7714	Drag Knob
RD1891	Multi-Purpose Screw	RD3474	"O" Ring	RD7715	Spool Assembly (aluminum)
RD2275	Bail Spring Guide (B)	RD3475	Anti-Reverse Pawl	RD7716	Bail Arm
RD2298	Spacer	RD3476	Anti-Reverse Pawl Spring	RD7717	Bail Spring Cover
RD2329	Bail Trip Lever Screw	RD3478	Worm Shaft Spacer	RD7718	Counterbalance Cover
RD2404	"E" Lock	RD3481	Bushing	RD7719	Rotor
RD2852	Handle Screw Lock	RD3485	Oscillating Slider Bushing	RD7720	Line Roller
RD3304	Bearing Spacer	RD3488	Oscillating Guide Holder	RD7721	Bail Assembly
RD3308	Line Roller Washer	RD3489	Oscillating Guide	RD7722	Side Cover
RD3309	Line Roller Screw	RD3936	Oscillating Pawl Cover Screw	RD7723	Handle Screw Cap
RD3366	Anti-Reverse Lever Screw	RD4053	Oscillating Pawl Cover	RD7724	Rear Protector
RD3402	Cover Screw	RD4054	Oscillating Slider	RD7725	Anti-Reverse Lever
RD3455	Spool Washer	RD4055	Slider Retainer Screw	RD7726	Handle Assembly
RD3456	Spool Support	RD4065	Worm B	RD7727	Body
RD3459	Bail Spring Guide (A)	RD4416	Bail Arm Screw	RD7889	Spool Assembly (graphite)
RD3462	Bail Trip Lever	RD4631	Spacer	RD8373	Line Roller Bearing
RD3464	Lock Out Spring Holder	RD4743	Line Roller Bushing	RD8553	Ball Bearing
RD3465	Anti-Reverse Lock Out Spring	RD4744	Roller Bearing Seal		
RD3466	Anti-Reverse Lock Out	RD4852	Main Shaft		