


SHIMANO®

SUPER AERO

SUA-8000F



Part No.	Description	Part No.	Description	Part No.	Description
RD0049	Lock Washer	RD3402	Cover Screw	RD4743	Line Roller Bushing
RD0521	Rotor Nut	RD3474	"O" Ring	RD4744	Roller Bearing Seal
RD0540	Bail Trip Lever Screw	RD3503	Spool Washer	RD5086	Worm Bushing
RD0690	Drive Gear Washer	RD3941	Bail Spring Spacer	RD5087	Worm Shaft
RD0787	Nut Lock Screw	RD3943	Bail Trip Lever	RD7743	Line Roller
RD0940	Bail Arm Screw	RD3945	Anti-Reverse Lock Out	RD7748	Drag Knob
RD1008	Handle Lock Washer	RD3946	Anti-Reverse Lock Out Spring	RD7749	Spool Assembly
RD1083	Oscillating Pawl Cover Screw	RD3947	Lock Out Spring Holder	RD7750	Bail Arm
RD1520	Anti-Reverse Cam Spring	RD3948	Bearing Retainer	RD7751	Bail Spring Cover
RD1511	Lever Spring	RD3950	Anti-Reverse Cam	RD7752	Counterbalance Cover
RD1891	Multi-Purpose Screw	RD3951	Anti-Reverse Pawl	RD7753	Rotor
RD2404	"E" Lock	RD3952	Anti-Reverse Pawl Spring	RD7754	Bail Assembly
RD2532	Bail Spring Guide (A)	RD3955	Idle Gear	RD7755	Side Cover Flange
RD2533	Bail Spring	RD3957	Main Shaft	RD7756	Side Cover
RD2534	Bail Spring Guide (B)	RD3958	Slider Retainer Screw	RD7757	Handle Screw Cap
RD2541	Anti-Reverse Pawl Screw	RD3959	Oscillating Slider	RD7758	Rear Protector
RD2572	Worm Shaft Spacer	RD3960	Oscillating Pawl	RD7759	Anti-Reverse Lever
RD3182	Spool Support	RD3961	Oscillating Slider Bushing	RD7760	Handle Assembly
RD3191	Multi-Purpose Screw	RD3962	Spacer	RD7761	Body
RD3195	Bushing	RD3963	Oscillating Pawl Cover	RD8372	Ball Bearing
RD3304	Bearing Spacer	RD3964	Drive Gear	RD8373	Line Roller Bearing
RD3308	Line Roller Washer	RD3966	Oscillating Guide	RD8374	Ball Bearing
RD3309	Line Roller Screw	RD3967	Oscillating Guide Holder	RD8667	Pinion Gear
RD3366	Anti-Reverse Lever Screw	RD4627	Side Cover Screw		
RD3387	Handle Screw Lock	RD4631	Spacer		