JHX



2000F 00

RoulementCasting.com

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0026	Ball Bearing	2852	Handle Screw Lock	3855	Lock Out Spring Holder
0041	Drive Gear Washer	3359	Line Roller Washer	3856	Anti-Reverse Pawl
0071	Rotor Nut	3397	Bail Spring	3857	Anti-Reverse Pawl Spring
0345	Anti-Reverse Lever Screw	3448	Spool Assembly	3858	Anti-Reverse Cam
0543	Side Cover Screw (black)	3455	Spool Washer	4351	Anti-Reverse Lever
0642	Side Cover Screw (silver)	3471	Anti-Reverse Cam Spring	4568	Bail Arm
0787	Nut Lock Screw	3645	Drag Knob	5625	Line Roller Spacer
0792	Bearing Retainer Screw	3646	Main Shaft	5628	Line Roller Collar
0940	Multi-Purpose Screw	3655	Cover Screw	5629	Line Roller Bushing
1008	Handle Lock Washer	3657	Pinion Gear	5630	Line Roller
1025	Handle Assembly	3662	Drive Gear	6787	Bail Spring Cover
1310	Line Roller Screw	3664	Oscillating Slider	6792	Bail Assembly
1427	Spool Support	3665	Slider Retainer Screw	6793	Rotor
1442	Handle Screw Cap	3673	Oscillating Gear	6794	Bail Trip Lever
1504	Bail Spring Cover Screw	3848	Bail Spring Guide (A)	6795	Counterbalance Cover
1506	Bail Trip Lever Screw	3849	Bail Spring Guide (B)	6796	Body Assembly
2283	Anti-Reverse Pawl Screw	3853	Anti-Reverse Lock Out		
2293	Drive Gear Bushing	3854	Anti-Reverse Lock Out Spring		

(120203)